Biltmore Outdoor Wicker Glass Top Table

CO7208-WB



PART LIST

 Wicker Top		 Side Panel	
A	1PC	B	2PCS
 End Panel		Glass Top	
C	2PCS	D	1PC

HARDWARE LIST

 Short Bolt(M6*40mm)		 Long Bolt(M6*50mm)	
E	4PCS	F	4PCS
Washer(M6mm)		Allen Key(M6mm)	
G	8PCS	H	12PCS

EXTRA HARDWARE LIST



E X1PC



F X2PCS

G X3PCS

Step 1. Lay wicker Top (A) on a flat surface with underside facing up. Attach Side Panels(B) to Top (A), using Short Bolts(E), Washers(G) and Allen Key (H).

NOTE: Please do not fully tighten bolts until unit is fully assembled.



Step 2. Attach End Panels (C) to Side Panels (B), using Long Bolts(F), Washers(G) and Allen Key(H).



Step 3. Turn the table upright and place the glass on the table top.