



2902-SECTPH (57H, 19, 23, 59H, 72, 58H) in fabric 959-80

FLEXSTEEL®

© Flexsteel Industries, Inc. | Last Updated 02/22

23 59H 19	58H 57H	FEATURES
		Flexsteel Spring Unit
●	●	DualFlex
		Back Construction
●	●	Attached
		Seat Construction
●	●	Attached
		Seat Cushion(s)
●	●	High-Density (HC)
	○	Tailoring
		Arm Covers

- Standard
○ Optional

PRODUCT DIMENSIONS	OVERALL			SEAT			Arm Height	Open Depth	Wall Clearance
	Height	Width	Depth	Height	Width	Depth			
Full Wedge -23	43"	64"	39"	21"	42"	25"			
Straight Console -72	42"	9"	39"	24"	9"	24"			
Armless Power Recliner with Power Headrest -59H	43"	27"	39"	23"	27"	21"		68"	5"
RAF Power Recliner with Power Headrest -58H	43"	33"	39"	23"	27"	21"	26"	68"	7"
LAF Power Recliner with Power Headrest -57H	43"	33"	39"	23"	27"	21"	26"	68"	7"
Armless Chair -19	43"	27"	40"	21"	27"	22"			

NOTES

Available in more than 250 fabric options

Also available in Performance fabrics - Revolution and LiveSmart

Straight console features two cup holders.

Removable backs allow for easy lifting and maneuvering through doorways.

The power control allows you to independently adjust the recline and headrest.


A separate home button returns the headrest and footrest to their original positions with one touch.

A USB port is included on the power control for powering electronics.

Zero draw technology only uses power when the USB port is in use.



Power Recline
& Headrest




Interlocking Brackets
Interlocking brackets securely attach one sectional component to another to prevent them from separating even when reclining.

2902 Davis Sectional | Components & Configurations


Reclining Sofas & Sectionals

Components

LAF = Left-Arm-Facing
RAF = Right-Arm-Facing



Sample Configurations



Scale 1/4" = 1'

Dimensions are in inches and are subject to variance.
© Flexsteel Industries, Inc. 10/18 | Rev 12/20
FLX-CP-FR-CC-2902

