



1659-60PH in 204-70

FLEXSTEEL®

© Flexsteel Industries, Inc. | Last Updated 02/24/2022

Fenwick | 1659

LEATHER

64PH  
62PH  
60PH  
54PH

**FEATURES**

**Flexsteel Spring Unit**

- DualFlex

**Back Construction**

- Attached

**Seat Construction**

- Attached

**Seat Cushion(s)**

- High-Density (HC)

- Standard
- Optional

**PRODUCT DIMENSIONS**

|   | OVERALL |       |       | SEAT   |       |       | Arm Height | Open Depth | Wall Clearance |
|---|---------|-------|-------|--------|-------|-------|------------|------------|----------------|
|   | Height  | Width | Depth | Height | Width | Depth |            |            |                |
| <b>Power Reclining Loveseat with Console &amp; Power Headrests</b><br>-64PH | 42"     | 79"   | 42"   | 20"    | 41"   | 22"   | 28"        | 69"        | 6"             |
| <b>Power Reclining Sofa with Power Headrests</b><br>-62PH                   | 42"     | 89"   | 42"   | 20"    | 63"   | 22"   | 28"        | 69"        | 6"             |
| <b>Power Reclining Loveseat with Power Headrests</b><br>-60PH               | 42"     | 67"   | 42"   | 20"    | 41"   | 22"   | 28"        | 69"        | 6"             |
| <b>Power Gliding Recliner with Power Headrest</b><br>-54PH                  | 42"     | 45"   | 42"   | 20"    | 19"   | 22"   | 28"        | 69"        | 12"            |

**Stocked Colors**



**204-70**  
Leather/Vinyl



**204-72**  
Leather/Vinyl

*Printed samples may vary from actual swatches. Please refer to swatches for actual color.*

**NOTES**

Upholstery Material: Leather/Vinyl

Removable backs allow for easy lifting and maneuvering through doorways.

Center console features two cup holders and a storage compartment.

Safety locks prevent furniture from gliding while reclining.

The power control allows you to independently adjust the recline and headrest.

A separate home button returns the headrest and footrest to their original positions with one touch.

A USB port is included on the power control for powering electronics.

Zero draw technology only uses power when the USB port is in use.



**Power Recline  
& Headrest**