

ASSEMBLY INSTRUCTIONS

MODEL #

FM3220 - BN


Questions?

GIVE US A CALL: 1-888-980-5122
MON-FRI 8:30AM - 5:30PM (PT)

TOOLS REQUIRED



Screwdriver
(Not included)



(Included)
Allen Wrench



2 - People

ASSEMBLY RATING



EASY —————> DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.

VERSION# 24-05-20



FOA Intro

Thank you for your purchase!

We hope you enjoy this new addition to your home for many years to come.

Our commitment to providing quality products does not simply end when you purchase our product. We fully stand behind our products from start to finish. Our customer service department is available Monday – Friday 8:30 AM – 5:30 PM Pacific Time and can help with assembly questions as well as, if necessary, replacing damaged or missing parts. To help expedite our service, please have these assembly instructions readily available, along with your order receipt.



Consumer Hotline
Toll-Free 1-888-980-5122



WEBSITE
www.foagroup.com



Monday to Friday
8:30AM- 5:30PM (PT)



E-MAIL
cs.ec@foagroup.com



foagroup



FurnitureOfAmerica



CHECK BEFORE STARTING



Are you missing anything?

Double-check all parts, hardware and accessories listed are all accounted for.



Check out our Quick Tips!

We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!



Should we send any replacements?

Are there any irregularities or flaws in the parts? We can send replacements!



Prep Time!

Please review the assembly instructions and all diagrams prior to assembling.

PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.



Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.



Suitable Location

Assembling near the area of the intended location is highly recommended.



Sufficient Space

Make sure you have enough space to move around during the assembly.



Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent to prevent scratches and damages.



Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

ASSEMBLY AND CARE ADVICE



**FAILURE TO FOLLOW THE GUIDELINES BELOW MAY
RESULT IN INJURY AND/OR PROPERTY DAMAGE.**



Position each part correctly
and insert screws or bolts into
their respective holes.



Turn clockwise to tighten and
only tighten when step is
completed or when instructed
to do so.



Use the appropriate hand tools
or power tools for assembly.
Select steps, such as tightening
screws and/or bolts, may require
hand tools to avoid causing
damage during assembly.



Save the instructions and store
any supplied tools for later
maintenance.




After two weeks, check and
tighten any loose hardware and
repeat again every six months
thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

BENCH FM3220 -BN




- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.




PARTS

P1 - 1PC



Bench Seat


P2 - 2 PCS



Bench Leg

HARDWARE

H1 12 PCS



M6X40MM JCBC SCREW

H2 12 PCS



SPRING WASHER

H3 12 PCS



FLAT WASHER

H4 4 PCS



WOOD DOWEL

H5 4 PCS




LEG GLIDE

H6 1 PC












ALLEN KEY



FM3220 - BN

is packed in 1 carton

Carton	Designation	Part List		Hardware List
FM3220 - BN	Bench Seat	P1 x 1pc		
	Bench Leg	P2 x 2pcs		
FM3220 - BN				 H1 x 12 pc M6x40 JCBC SCREW
				 H2 x 12 pc Spring Washer
				 H3 x 12 pc Flat Washer
				 H4 x 4 pc Wood Dowel M8x30mm
				 H5 x 4 pc LEG GLIDE
				 H6 x 1 pc Allen Key









ASSEMBLY INSTRUCTIONS


FM3220 - BN

PARTS LIST

NO.	COMPONENT	QTY.
P1	BENCH SEAT	1
P2	BENCH LEG	2

HARDWARE LIST

NO.	DESCRIPTION	QTY.
H1	M6X40MM JCBC SCREW 	12
H2	SPRING WASHER 	12
H3	FLAT WASHER 	12
H4	WOOD DOWEL M8 x 30mm 	4
H5	LEGS ADJUSTABLE GLIDE 	4
H6	ALLEN KEY 	1





COMPLETE ASSEMBLY

* MALLET (NOT PROVIDED)

STEP 1




Lay the table top (P1) upside down on a flat soft & clean surface.
Prepare the table leg (P2) by inserting the wooden dowel into the designated holes.


H4 x 4 
M8 x 30mm




STEP 2

Align and attach the table leg (P2) to the table top (P1) by using assembly of Bolt (H1) with spring washer (H2) and flat washer (H3).

H1 x 6 
M6 x 40mm
H2 x 6 
H3 x 6 




STEP 3




Assemble the other side of Bench leg (P2) by attaching it to the apron in the Bench Seat, and make sure the locating wooden dowels in the bench leg are snug in the holes at the bench seat.

Then, Align Bolt (H1) fitted with a Spring Washer (H2) & a Flat Washer (H3) through the holes in the connecting blocks, respectively.


Tighten the bolts using the Allen Key (H6).



STEP 4



Attach the leg glide (H5) to the table base (P2)..




THEN, CAREFULLY PUT THE TABLE UPRIGHT

CARE AND MAINTENANCE

SAFETY - To avoid any risk of suffocation to children or animals, dispose off the plastic bags immediately.

CLEANING - Clean with damp cloth and mild detergent. Do not use bleach or abrasive products.

FITTINGS - Tighten bolts and nuts from time to time to ensure all parts of product are securely fitted.



ASSEMBLY COMPLETED



Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.



Keep this handy!

Please retain this instruction manual and any order-related information for future reference.



Lift, don't drag!

To avoid damage to product please always LIFT the product when transporting or adjusting the placement.

This product is intended for RESIDENTIAL USE ONLY and not for commercial use .

CARE AND MAINTENANCE

SAFETY - To avoid any risk of suffocation to children or animals, dispose off the plastic bags immediately.

CLEANING - Clean with damp cloth and mild detergent. Do not use bleach or abrasive products.

FITTINGS - Tighten bolts and nuts from time to time to ensure all parts of product are securely fitted.