






A




x1 Table Top
x1 Dessus de la table
x1 Mesa parte superior

L




x1 Leg (Left)*
x1 Jambe (gauche)
x1 Pierna (izquierda)

R




x1 Leg (Right)*
x1 Jambe (droite)
x1 Pierna (derecha)

C



x1 Bottom shelf *
x1 Étagère inférieure
x1 Estante inferior



x4 Caster *
x4 Roulette
x4 Castor

E



x4 Allen bolt Ø5/16"x38mm*
x4 Boulon Ø5/16"x38mm
x4 Perno Allen Ø5/16"x38mm

F



x6 Allen bolt Ø5/16"x58mm*
x6 Boulon Ø5/16"x58mm
x6 Perno Allen Ø5/16"x58mm

G



x14 Lock washer Ø5/16"*
x14 Rondelle de blocage Ø5/16"
x14 Arandela de Seguridad Ø5/16"

H



x14 Flat Washer Ø5/16"x19x1.5mm*
x14 Rondelle plate Ø5/16"x19x1.5mm
x14 Arandela plana Ø5/16"x19x1.5mm

I



x1 Allen Key 4mm*
x1 Clé hexagonale 4mm
x1 Llave Allen 4mm

K




x4 Dowel Ø8*30*
x4 Goujon Ø8*30
x4 Clavija Ø8*30

L





x1 Open Wrench 13mm*
x1 Clé à fourche 13mm
x1 Llave de boca 13mm


* Replaceable Part




* Replaceable Part



x1 RS762DJ-100-LEGL- Legs (Left)*
Jambes (gauche)
Piernas (izquierda)




x1 RS762DJ-100-LEGR- Legs (Right)*
Jambes (droite)
Piernas (derecha)



x1 RS762DJ-100-OSHELF-Bottom shelf*
-Étagère inférieure
-Estante inferior




x2 RS762DJ-100 - BUTTON*
Button with Screw
Bouton et vis
Botón y Tornillo



x4 RS762DJ-100-Caster*
-Roulette
-Castor



x4 RC-WH-NAIL-White Plastic Nail*
Clou en plastique
Clavo de plástico



x1 RS762DJ-100-HWKIT-Hardware Kit*
-Liste des pièces de quincaillerie
-Lista de materiales

* Replaceable Part