



ITEM #: YS500PTTS / YS500PTBS
DESCRIPTION: YVES COUNTER TABLE TOP /
STORAGE TABLE BASE
PRODUCT SIZE: 42" x 78" x 36"H (With 14" Leaf)

Your furniture purchase is an investment. Here are a few tips to maximize the lifetime of your furniture with a minimum amount of effort. Properly caring for your furniture can help ensure that it looks great year after year.

Wood Furniture Maintenance:

- Always dust, wipe, and clean *with* the grain of the wood.
- Dust with a soft cloth. Dust will scratch the furniture surface if not removed properly.
- Use the same type of polish consistently as interchanging oil-based and wax-based polishes will cause a build-up and result in a foggy or cloudy appearance.
- If a polished surface becomes foggy, rub it with a cloth dipped in a solution of one tablespoon vinegar to one quart of water. Rub softly with the grain until the surface is completely dry.
- Soap and water are not advisable for wood surfaces. Water can penetrate the finish and raise the grain on wood, causing damage.
- Remember to change dusting cloths frequently as dirty cloths may scratch your furniture's surface

The Enemies of Wood:

- Moisture is wood's worst enemy. Liquid spills should be gently wiped up immediately. Coasters should be used under all beverages.
- Do not allow rubber or vinyl materials to lie on the furniture. Chemicals in rubber may leave a stain. Put a strip of felt or leather under accessories that have rubber or vinyl.
- Heat creates a chemical change in the furniture's finish, which results in a white spot. Use protective pads under hot dishes, appliances, etc.
- Sunlight's ultraviolet rays can damage the finish of furniture. Do not place furniture directly against a heater or radiator and do not place in the path of hot streams of air from central heating. This will cause extreme localized drying of the wood.

High Gloss Resin Table Maintenance:

- Resin tabletops have approximately 1/8" of a resin coat on the top face of the table, which will resist ice, water, wine, liquor, food, cleaning fluids, and warm or hot liquids; however, cups, glasses, etc. containing hot liquids should not be left on the table without a coaster for protection.
- Resin tabletops will scratch just the same as any other glossy surface and basic precautions should be taken.
- For lasting shine, the resin table should be waxed with a car wax that does not contain silicon. Maintaining this wax build-up will result in a high gloss shine.
- When wiping down the table, a soft, clean rag should be used. Do not use a heavy paper.

Granite Top Maintenance:

The surface of the granite on your table has been polished or sealed to create a generally non-porous surface. The stone has many natural characteristics including: veining, hairline cracks, and color variations - which make up the stone's beauty.

To maintain the beauty of your granite:

- Protect surfaces from scratching, staining and etching by:
 - * Keeping them free of debris or sharp objects
 - * Wiping up spills immediately
 - * Avoiding contact with chemicals (particularly acid-based materials)
- Clean with pH neutral products or those especially formulated for use on stone.
- It is not recommended to use a water-based solvent for dark granite as it will remove the polish from the surface. Absorbed into the stone.
- After a period of use, apply a penetrating sealer to prevent contaminants from being
- Remove stains with special absorbent poultices formulated for use on stone.
- Renew the surface on polished granite (granite with a high gloss surface) by buffing with special stone polish, powder or cream.
- Do not use granite polish on granite with a matte finish, which has been honed rather than polished. (Penetrating sealer may be used on both polished and honed granite.)

Marble Top Maintenance:

Marble may be stone, but it is porous stone and can stain easily. Treating marble surfaces the same as wood surfaces is a great rule of thumb.

- It is recommended to seal the tops on a regular basis (every 6 to 12 months).

A good quality stone sealer can be purchased from any tiles / stone store or any homecare store and should be applied according to the manufacturer's recommendation.

- When sealed properly, marble tops can be used indoors and outdoors and can withstand any weather conditions except internal freezing. Snow or freezing rain will penetrate the table and cause cracks.

Caring for the Fabric on Upholstered Furniture:

- Frequent vacuuming of the entire upholstered area will prevent dust from settling into the fibers.
- Professional cleaning is always recommended for all upholstered pieces.
- Always pre-test a small area of fabric in an inconspicuous area when cleaning before proceeding.
- Do not use cleaning products containing brightening agents.

VERY IMPORTANT!!

NEVER

USE GLASS CLEANERS ON FINISHED SURFACES. AMMONIA WILL CHEMICALLY ATTACK THE FINISH.

DO NOT WRITE DIRECTLY ON SURFACE



PREVENT MARKING

DO NOT PLACE DIRECTLY IN SUNLIGHT



PREVENT FADING

DO NOT USE PLACEMATS WITH RUBBER BASES



PREVENT DISCOLORING

NEVER

ALLOW LIQUIDS OF ANY KIND TO LINGER ON SURFACES. ABSORPTION CAUSES THE WOOD TO WARP AND THE FINISH TO DE-LAMINATE.

DO NOT USE COMMERCIAL POLISHES AND WAXES



PREVENT YELLOWING

DO NOT PLACE HOT POTS, ETC. ON SURFACE



PREVENT DAMAGE TO FINISH!

REGULATE THE HUMIDITY CONDITIONS AT YOUR HOME




PREVENT SPLITTING

YS500PTTS / YS500PTBS


ASSEMBLY INSTRUCTIONS

P.2/5


DO NOT FULLY TIGHTEN ALL BOLTS AND HEX NUTS UNTIL THE ENTIRE UNIT IS COMPLETELY ASSEMBLED



Step 1: Attach 2 Table Leg (C) to the corners of the Table Base (B) by inserting Bolt (1), Lock Washer (2), Flat Washer (3) and tighten with Wrench (5). Do not fully tighten.



Step 2: Attach last 2 Table Leg (C) to the corners of the Table Base (B) by inserting Bolt (1), Lock Washer (2), Flat Washer (3) and tighten with Wrench (5) as the picture shown. Do not fully tighten.




Step 3: Turning the assembly base in step 2 to upright position. Attach the Mounting Plate (D) on the top of 4 Table Leg (C) by inserting Hex Nut (4), Lock Washer (2), Flat Washer (3) and tighten with Wrench (5) as the picture shown. Fully tighten all Bolts and Hex Nuts in Step 1,2,3 at this time. Do not over tighten.

YS500PTTS / YS500PTBS


ASSEMBLY INSTRUCTIONS

P.3/5


DO NOT FULLY TIGHTEN ALL BOLTS AND HEX NUTS UNTIL THE ENTIRE UNIT IS COMPLETELY ASSEMBLED



Step 4: Place Table Top (A) upside down on a piece of cloth or carpet to prevent finish from scratching. Attach the Assembly Base in Step 3 to the table slide of the Table Top (A) by using Bolt (1), Lock Washer (2), Flat Washer (3) and fully tighten with Wrench (4) as the picture shown. Do not over tighten.










Step 5: Turning the Table to upright position . Insert the Shelf Clip (6) into the pre-drill holes inside of the Table Base (B) and put the Shelf (E) on to the Shelf Clip (6). Unlock the Latch underneath the Table Top (A) pull the Table Top (A) from both ends. Insert Table Leaf (F) to the middle of Table Top (A), close the Table Top (A) by pushing from both ends. Lock the latch underneath the Table Top (A) to prevent from sliding. Assembly of product is now completed.









Step 6: Take the Sliding Door (G) out of the box and press down the pin as the picture (1-1). Attach the Sliding Door (G) to the Table Base (B) by aligning the door into the top groove and the bottom groove at the same time and then press up the pin as the picture (2-2) & (3-3). Assembly is now completed.


PART LIST

(A) TABLE TOP (1 PC)	(B) TABLE BASE (1 PC)	(C) TABLE LEG (4 PCS)	
			
(D) MOUNTING PLATE (2 PCS)	(E) SHELF (2 PCS)	(F) TABLE LEAF (1 PC)	(G) SLIDING DOOR (4 PCS)
			

HARDWARE PACK # : PYS500PTSH

NO.	DESCRIPTION		DIMENSION	Q'TY
1	Bolt		$\Phi \frac{1}{4}" \times 50 \text{ mm}$	16 pcs
2	Lock Washer		$\Phi \frac{5}{16}" \times 13 \text{ mm}$	20 pcs
3	Flat Washer		$\Phi \frac{5}{16}" \times 19 \text{ mm}$	20 pcs
4	Hex Nut		$\Phi \frac{5}{16}" \times 12 \text{ mm}$	4 pcs
5	Hex Wrench		12 mm	1 pc
6	Shelf Clip			8 pcs

**PARTS FOR YS500PTTS / YS500PTBS
COMPLETE HARDWARE # : PYS500PTSH**



PRODUCT DETAILS

TABLE TOP	MDF w/ OAK VENEER
TABLE LEG	ACACIA WOOD
TABLE BASE	MDF w/ OAK VENEER + RUBBER WOOD
SHELF	MDF w/ LOCAL VENEER
PRODUCT SIZE TOP	42" x 78" (With 14" Leaf)
PRODUCT SIZE BASE	36"H
CARTON SIZE TOP	67.5" x 46.25" x 7" H
CARTON SIZE BASE	50.0" x 25.75" x 22.75" H
NET WEIGHT TOP	56 LBS
NET WEIGHT BASE	45 LBS
GROSS WEIGHT TOP	63 LBS
GROSS WEIGHT BASE	51 LBS
CU.FT. TOP	12.65'
CU.FT. BASE	16.95'

MADE IN VIETNAM



Item #: YS500CCG

Description: YVES COUNTER CHAIR GREY

Product Size: 20" x 20.35" x 42" H

Your furniture purchase is an investment. Here are a few tips to maximize the lifetime of your furniture with a minimum amount of effort. Properly caring for your furniture can help ensure that it looks great year after year.

Wood Furniture Maintenance:

- Always dust, wipe, and clean *with* the grain of the wood.
- Dust with a soft cloth. Dust will scratch the furniture surface if not removed properly.
- Use the same type of polish consistently as interchanging oil-based and wax-based polishes will cause a build-up and result in a foggy or cloudy appearance.
- If a polished surface becomes foggy, rub it with a cloth dipped in a solution of one tablespoon vinegar to one quart of water. Rub softly with the grain until the surface is completely dry.
- Soap and water are not advisable for wood surfaces. Water can penetrate the finish and raise the grain on wood, causing damage.
- Remember to change dusting cloths frequently as dirty cloths may scratch your furniture's surface

The Enemies of Wood:

- Moisture is wood's worst enemy. Liquid spills should be gently wiped up immediately. Coasters should be used under all beverages.
- Do not allow rubber or vinyl materials to lie on the furniture. Chemicals in rubber may leave a stain. Put a strip of felt or leather under accessories that have rubber or vinyl.
- Heat creates a chemical change in the furniture's finish, which results in a white spot. Use protective pads under hot dishes, appliances, etc.
- Sunlight's ultraviolet rays can damage the finish of furniture. Do not place furniture directly against a heater or radiator and do not place in the path of hot streams of air from central heating. This will cause extreme localized drying of the wood.

High Gloss Resin Table Maintenance:

- Resin tabletops have approximately 1/8" of a resin coat on the top face of the table, which will resist ice, water, wine, liquor, food, cleaning fluids, and warm or hot liquids; however, cups, glasses, etc. containing hot liquids should not be left on the table without a coaster for protection.
- Resin tabletops will scratch just the same as any other glossy surface and basic precautions should be taken.
- For lasting shine, the resin table should be waxed with a car wax that does not contain silicon. Maintaining this wax build-up will result in a high gloss shine.
- When wiping down the table, a soft, clean rag should be used. Do not use a heavy paper.

Granite Top Maintenance:

The surface of the granite on your table has been polished or sealed to create a generally non-porous surface. The stone has many natural characteristics including: veining, hairline cracks, and color variations - which make up the stone's beauty.

To maintain the beauty of your granite:

- Protect surfaces from scratching, staining and etching by:
 - * Keeping them free of debris or sharp objects
 - * Wiping up spills immediately
 - * Avoiding contact with chemicals (particularly acid-based materials)
- Clean with pH neutral products or those especially formulated for use on stone.
- It is not recommended to use a water-based solvent for dark granite as it will remove the polish from the surface. Absorbed into the stone.
- After a period of use, apply a penetrating sealer to prevent contaminants from being
- Remove stains with special absorbent poultices formulated for use on stone.
- Renew the surface on polished granite (granite with a high gloss surface) by buffing with special stone polish, powder or cream.

Do not use granite polish on granite with a matte finish, which has been honed rather than polished. (Penetrating sealer may be used on both polished and honed granite.)

Marble Top Maintenance:

Marble may be stone, but it is porous stone and can stain easily. Treating marble surfaces the same as wood surfaces is a great rule of thumb.

- It is recommended to seal the tops on a regular basis (every 6 to 12 months).

A good quality stone sealer can be purchased from any tiles / stone store or any homecare store and should be applied according to the manufacturer's recommendation.

- When sealed properly, marble tops can be used indoors and outdoors and can withstand any weather conditions except internal freezing. Snow or freezing rain will penetrate the table and cause cracks.

Caring for the Fabric on Upholstered Furniture:

- Frequent vacuuming of the entire upholstered area will prevent dust from settling into the fibers.
- Professional cleaning is always recommended for all upholstered pieces.
- Always pre-test a small area of fabric in an inconspicuous area when cleaning before proceeding.
- Do not use cleaning products containing brightening agents.

VERY IMPORTANT!!

NEVER
USE GLASS CLEANERS
ON FINISHED SURFACES.
AMMONIA WILL
CHEMICALLY ATTACK
THE FINISH.

DO NOT
WRITE
DIRECTLY
ON
SURFACE



**PREVENT
MARKING**

DO NOT
PLACE
DIRECTLY
IN
SUNLIGHT



**PREVENT
FADING**

DO NOT
USE
PLACEMATS
WITH
RUBBER
BASES



**PREVENT
DISCOLORING**

NEVER
ALLOW LIQUIDS OF ANY
KIND TO LINGER ON
SURFACES. ABSORPTION
CAUSES THE WOOD TO
WARP AND THE FINISH
TO DE-LAMINATE.

DO NOT USE
COMMERCIAL
POLISHES
AND WAXES



**PREVENT
YELLOWING**

DO NOT
PLACE HOT
POTS, ETC.
ON
SURFACE



**PREVENT
DAMAGE TO
FINISH!**

REGULATE
THE
HUMIDITY
CONDITIONS
AT YOUR
HOME




**PREVENT
SPLITTING**


YS500CCG

ASSEMBLY INSTRUCTIONS

DO NOT FULLY TIGHTEN ALL BOLTS AND HEX NUTS UNTIL THE ENTIRE UNIT IS COMPLETELY ASSEMBLED




Step 1: Place the Chair back (A) on the floor. Attach Seat Box w/Seat Cushion () to the Chair back (A) by inserting the Short Bolt (2), Lock Washer (), Flat Washer () into the holes at the rear bar of the seat frame. Long Bolt (1), Lock Washer (), Flat Washer () into the holes at the rear corner block of the Seat Box. Tighten all bolts with Wrench (6). Do not fully tighten.










Step 2: Attach the Left / Right Front Leg (C/D) to the Seat Box w/Seat Cushion () by using Flat Washer (), Lock washer () and Hex Nut (5), secure by Hex Wrench (6). Do not fully tighten.

Attach the Left/Right Side Stretcher (F/) to Left/Right Front Leg (C/D) and Chair back (A). Insert the Front Stretcher () to the middle of Left/Right Front Leg (C/D) by using Pan Head Screw () with Phillip -head screwdriver (not provided).








Step 3: Place the Chair to upright position on flat surface and adjust legs until level and does not wobble. Fully tighten all bolts and Hex nuts with Wrench (6). Assembly of product is completed.




PART LIST

(A) CHAIR BACK (1PC)	(B) SEAT BOX W/ SEAT CUSHION (1PC)	(C) LEFT FRONT LEG (1PC)	(D) RIGHT FRONT LEG (1PC)
			
	(E) FRONT STRETCHER (1PC)	(F) LEFT SIDE STRETCHER (1PC)	(G) RIGHT SIDE STRETCHER (1PC)
			

HARDWARE PACK # : PYS500CCGH

NO.	DESCRIPTION		DIMENSION	Q'TY
1	Long Bolt		$\frac{1}{4}$ " x 75 mm	4 pcs
2	Short Bolt		$\frac{1}{4}$ " x 40 mm	3 pcs
3	Lock Washer		$\frac{5}{16}$ " x 13 mm	11 pcs
4	Flat Washer		$\frac{5}{16}$ " x 19 mm	11 pcs
5	Hex Nut		$\frac{5}{16}$ " x 12 mm	4 pcs
6	Wrench		12 mm	1 pc
7	Pan Head Screw		4 mm x 40 mm	6 pcs

**PARTS OR YS500CCG
COMPLETE HARDWARE # : PYS500CCGH**



A RIC CONTENT: 00 POLYESTER I ER

Th s a r c s not mach ne washa le

Allow / 3 res dual shr nkage

Do not use clean ng products conta n ng r ghten ng agents

Clean ng code WS

PROD CT DETAILS

CHAIR BACK
SEAT BOX
FRONT LEG
STRETCHER
PRODUCT SI E
CARTON SI E
NET WEIGHT
GROSS WEIGHT
CU.FT.

MANGO WOOD/ACACIA WOOD
ACACIA WOOD/ RUBER WOOD
ACACIA WOOD
RUBBER WOOD
20" x 20.35" x 42" H
43.70" x 20.47" x 15.55" H
46.2 LBS/ 2PCS
52. LBS/ 2PCS
.05'/ 2PCS

MADE IN IETNAM

Steve Silver Company Dining Chairs

- Assembly Troubleshooting Guide

The most important element of correct chair assembly is to tighten the bolts as directed. Prematurely tightening the bolts can lead to numerous issues and will lengthen the assembly time. Listed below are the most common issues in chair assembly and their easy solutions.

PROBLEM: Chair is unlevel.

Cause 1:

Unlevel chairs can occur if the bolts are fully tightened before all bolts are attached. There is a variance in the alignment of this chair to allow the chair to be assembled more easily.

Solution:

Loosen each bolt in the seat box (front legs, back corner blocks and back apron) until they are finger tight. Place the chair upright on the floor. Sit in the chair for about 30 seconds. Carefully turn the chair upside down and tighten each bolt. The chair will now be level.

Cause 2:

Unlevel chairs can occur if one or more of the floor glides are missing from the bottom of the chair leg.

Solution:

Request a set of floor glides from the e-mail address below.

AR@ssilver.com

PROBLEM: Bolts do not fit properly.

Cause:

This issue can occur when the bolts are tightened fully before all bolts are attached. There is a variance in the alignment of the bolts to allow the chair to be assembled more easily. Tightening the bolts prematurely can cause the holes for the other bolts to become slightly misaligned, causing the remaining bolts not to fit properly.

Solution:

Make sure each bolt in the seat box (front legs, back corner blocks and back apron) is loosened until finger tight. This will allow you to realign the holes, and the bolts will now fit properly.

Questions?

Please call us at 1 800 344 7278, and we will be happy to help you.



Item #: YS500CCBN
Description: YVES COUNTER BENCH
Product Size: 46.5" x 16.5" x 24"H

Your furniture purchase is an investment. Here are a few tips to maximize the lifetime of your furniture with a minimum amount of effort. Properly caring for your furniture can help ensure that it looks great year after year.

Wood Furniture Maintenance:

- Always dust, wipe, and clean *with* the grain of the wood.
- Dust with a soft cloth. Dust will scratch the furniture surface if not removed properly.
- Use the same type of polish consistently as interchanging oil-based and wax-based polishes will cause a build-up and result in a foggy or cloudy appearance.
- If a polished surface becomes foggy, rub it with a cloth dipped in a solution of one tablespoon vinegar to one quart of water. Rub softly with the grain until the surface is completely dry.
- Soap and water are not advisable for wood surfaces. Water can penetrate the finish and raise the grain on wood, causing damage.
- Remember to change dusting cloths frequently as dirty cloths may scratch your furniture's surface

The Enemies of Wood:

- Moisture is wood's worst enemy. Liquid spills should be gently wiped up immediately. Coasters should be used under all beverages.
- Do not allow rubber or vinyl materials to lie on the furniture. Chemicals in rubber may leave a stain. Put a strip of felt or leather under accessories that have rubber or vinyl.
- Heat creates a chemical change in the furniture's finish, which results in a white spot. Use protective pads under hot dishes, appliances, etc.
- Sunlight's ultraviolet rays can damage the finish of furniture. Do not place furniture directly against a heater or radiator and do not place in the path of hot streams of air from central heating. This will cause extreme localized drying of the wood.

High Gloss Resin Table Maintenance:

- Resin tabletops have approximately 1/8" of a resin coat on the top face of the table, which will resist ice, water, wine, liquor, food, cleaning fluids, and warm or hot liquids; however, cups, glasses, etc. containing hot liquids should not be left on the table without a coaster for protection.
- Resin tabletops will scratch just the same as any other glossy surface and basic precautions should be taken.
- For lasting shine, the resin table should be waxed with a car wax that does not contain silicon. Maintaining this wax build-up will result in a high gloss shine.
- When wiping down the table, a soft, clean rag should be used. Do not use a heavy paper.

Granite Top Maintenance:

The surface of the granite on your table has been polished or sealed to create a generally non-porous surface. The stone has many natural characteristics including: veining, hairline cracks, and color variations - which make up the stone's beauty.

To maintain the beauty of your granite:

- Protect surfaces from scratching, staining and etching by:
 - * Keeping them free of debris or sharp objects
 - * Wiping up spills immediately
 - * Avoiding contact with chemicals (particularly acid-based materials)
- Clean with pH neutral products or those especially formulated for use on stone.
- It is not recommended to use a water-based solvent for dark granite as it will remove the polish from the surface. Absorbed into the stone.
- After a period of use, apply a penetrating sealer to prevent contaminants from being
- Remove stains with special absorbent poultices formulated for use on stone.
- Renew the surface on polished granite (granite with a high gloss surface) by buffing with special stone polish, powder or cream.
- Do not use granite polish on granite with a matte finish, which has been honed rather than polished. (Penetrating sealer may be used on both polished and honed granite.)

Marble Top Maintenance:

Marble may be stone, but it is porous stone and can stain easily. Treating marble surfaces the same as wood surfaces is a great rule of thumb.

- It is recommended to seal the tops on a regular basis (every 6 to 12 months).

A good quality stone sealer can be purchased from any tiles / stone store or any homecare store and should be applied according to the manufacturer's recommendation.

- When sealed properly, marble tops can be used indoors and outdoors and can withstand any weather conditions except internal freezing. Snow or freezing rain will penetrate the table and cause cracks.

Caring for the Fabric on Upholstered Furniture:

- Frequent vacuuming of the entire upholstered area will prevent dust from settling into the fibers.
- Professional cleaning is always recommended for all upholstered pieces.
- Always pre-test a small area of fabric in an inconspicuous area when cleaning before proceeding.
- Do not use cleaning products containing brightening agents.

VERY IMPORTANT!!

NEVER

USE GLASS CLEANERS ON FINISHED SURFACES. AMMONIA WILL CHEMICALLY ATTACK THE FINISH.

DO NOT WRITE DIRECTLY ON SURFACE



PREVENT MARKING

DO NOT PLACE DIRECTLY IN SUNLIGHT



PREVENT FADING

DO NOT USE PLACEMATS WITH RUBBER BASES



PREVENT DISCOLORING

NEVER

ALLOW LIQUIDS OF ANY KIND TO LINGER ON SURFACES. ABSORPTION CAUSES THE WOOD TO WARP AND THE FINISH TO DE-LAMINATE.

DO NOT USE COMMERCIAL POLISHES AND WAXES



PREVENT YELLOWING

DO NOT PLACE HOT POTS, ETC. ON SURFACE



PREVENT DAMAGE TO FINISH!


REGULATE THE HUMIDITY CONDITIONS AT YOUR HOME




PREVENT SPLITTING

ASSEMBLY INSTRUCTIONS

DO NOT FULLY TIGHTEN ALL BOLTS AND HEX NUTS UNTIL THE ENTIRE UNIT IS COMPLETELY ASSEMBLED




Step 1: Attach Left Bench Leg(B) and Right Bench Leg (C) to the corner block of the Seat Box w/ Seat Cushion (A) by inserting Hex Nut (1), Lock Washer (2), Flat Washer (3) and tighten with Wrench (5). Attach the Long Stretcher (E) in the middle of 2 Bench Leg (B);(C) by inserting Pan-Head Screw (4) and tighten with phillips-head screwdriver (not provided). Do not fully tighten.




Step 2: Attach the Side Stretcher (D) to the Bench Leg (B);(C) by inserting Pan-Head Screw (4) and tighten with phillips-head screwdriver (not provided). Do not fully tighten.






Step 3: Attach the last Left Bench Leg(B) and Right Bench Leg (C) to the corner block of the Seat Box w/ Seat Cushion (A) by inserting Hex Nut (1), Lock Washer (2), Flat Washer (3) and tighten with Wrench (5). Attach the last Long Stretcher (E) in the middle of 2 Bench Leg (B);(C) by inserting Pan-Head Screw (4) and tighten with phillips-head screwdriver (not provided). Place Bench upright side position on flat surface and adjust Bench legs until level and not wobble. Fully tighten all hex nuts and Screws with Hex Wrench (5) and phillips-head screwdriver (not provided). Assembly product is completed.








Finish




PART LIST

(A) SEAT BOX W/ SEAT CUSHION (1PC)		(B) LEFT BENCH LEG (2PCS)	
			
(C) RIGHT BENCH LEG (2PCS)	(D) SIDE STRETCHER (2PCS)	(E) LONG STRETCHER (2PCS)	
			

HARDWARE PACK # : PYS500CCBNH

NO.	DESCRIPTION		DIMENSION	Q'TY
1	Hex Nut		$\Phi \frac{5}{16}$ " x 12 mm	8 pcs
2	Lock Washer		$\Phi \frac{5}{16}$ " x 13 mm	8 pcs
3	Flat Washer		$\Phi \frac{5}{16}$ " x 19 mm	8 pcs
4	Pan-Head Screw		$\Phi 4$ x 40 mm	8 pcs
5	Hex Wrench		12 mm	1 pc

PARTS FOR YS500CCBN
COMPLETE HARDWARE # : PYS500CCBNH



FABRIC CONTENT : 100% POLYESTER FIBRE

This fabric is not machine washable.

Allow +/- 3% residual shrinkage.

Do not use cleaning products containing brightening agents.

PRODUCT DETAILS

SEAT BOX

LEG

STRETCHER

PRODUCT SIZE

CARTON SIZE

NET WEIGHT

GROSS WEIGHT

CU.FT.

RUBBER WOOD

RUBBER WOOD

RUBBER WOOD

46.5" x 16.5" x 24"H

48.75" x 19.25" x 6.5" H

13 LBS

15 LBS

3.53'

MADE IN VIETNAM



Item #: YS500SV
Description: YVES SERVER
Product Size: 60" x 18" x 36" H

Your furniture purchase is an investment. Here are a few tips to maximize the lifetime of your furniture with a minimum amount of effort. Properly caring for your furniture can help ensure that it looks great year after year.

Wood Furniture Maintenance:

- Always dust, wipe, and clean *with* the grain of the wood.
- Dust with a soft cloth. Dust will scratch the furniture surface if not removed properly.
- Use the same type of polish consistently as interchanging oil-based and wax-based polishes will cause a build-up and result in a foggy or cloudy appearance.
- If a polished surface becomes foggy, rub it with a cloth dipped in a solution of one tablespoon vinegar to one quart of water. Rub softly with the grain until the surface is completely dry.
- Soap and water are not advisable for wood surfaces. Water can penetrate the finish and raise the grain on wood, causing damage.
- Remember to change dusting cloths frequently as dirty cloths may scratch your furniture's surface

The Enemies of Wood:

- Moisture is wood's worst enemy. Liquid spills should be gently wiped up immediately. Coasters should be used under all beverages.
- Do not allow rubber or vinyl materials to lie on the furniture. Chemicals in rubber may leave a stain. Put a strip of felt or leather under accessories that have rubber or vinyl.
- Heat creates a chemical change in the furniture's finish, which results in a white spot. Use protective pads under hot dishes, appliances, etc.
- Sunlight's ultraviolet rays can damage the finish of furniture. Do not place furniture directly against a heater or radiator and do not place in the path of hot streams of air from central heating. This will cause extreme localized drying of the wood.

High Gloss Resin Table Maintenance:

- Resin tabletops have approximately 1/8" of a resin coat on the top face of the table, which will resist ice, water, wine, liquor, food, cleaning fluids, and warm or hot liquids; however, cups, glasses, etc. containing hot liquids should not be left on the table without a coaster for protection.
- Resin tabletops will scratch just the same as any other glossy surface and basic precautions should be taken.
- For lasting shine, the resin table should be waxed with a car wax that does not contain silicon. Maintaining this wax build-up will result in a high gloss shine.
- When wiping down the table, a soft, clean rag should be used. Do not use a heavy paper.

Granite Top Maintenance:

The surface of the granite on your table has been polished or sealed to create a generally non-porous surface. The stone has many natural characteristics including: veining, hairline cracks, and color variations - which make up the stone's beauty.

To maintain the beauty of your granite:

- Protect surfaces from scratching, staining and etching by:
 - * Keeping them free of debris or sharp objects
 - * Wiping up spills immediately
 - * Avoiding contact with chemicals (particularly acid-based materials)
- Clean with pH neutral products or those especially formulated for use on stone.
- It is not recommended to use a water-based solvent for dark granite as it will remove the polish from the surface. Absorbed into the stone.
- After a period of use, apply a penetrating sealer to prevent contaminants from being
- Remove stains with special absorbent poultices formulated for use on stone.
- Renew the surface on polished granite (granite with a high gloss surface) by buffing with special stone polish, powder or cream.
- Do not use granite polish on granite with a matte finish, which has been honed rather than polished. (Penetrating sealer may be used on both polished and honed granite.)

Marble Top Maintenance:

Marble may be stone, but it is porous stone and can stain easily. Treating marble surfaces the same as wood surfaces is a great rule of thumb.

- It is recommended to seal the tops on a regular basis (every 6 to 12 months).
- A good quality stone sealer can be purchased from any tiles / stone store or any homecare store and should be applied according to the manufacturer's recommendation.

- When sealed properly, marble tops can be used indoors and outdoors and can withstand any weather conditions except internal freezing. Snow or freezing rain will penetrate the table and cause cracks.

Caring for the Fabric on Upholstered Furniture:

- Frequent vacuuming of the entire upholstered area will prevent dust from settling into the fibers.
- Professional cleaning is always recommended for all upholstered pieces.
- Always pre-test a small area of fabric in an inconspicuous area when cleaning before proceeding.
- Do not use cleaning products containing brightening agents.

VERY IMPORTANT!!

NEVER
USE GLASS CLEANERS
ON FINISHED SURFACES.
AMMONIA WILL
CHEMICALLY ATTACK
THE FINISH.

DO NOT
WRITE
DIRECTLY
ON
SURFACE



**PREVENT
MARKING**

DO NOT
PLACE
DIRECTLY
IN
SUNLIGHT



**PREVENT
FADING**

DO NOT
USE
PLACEMATS
WITH
RUBBER
BASES



**PREVENT
DISCOLORING**

NEVER
ALLOW LIQUIDS OF ANY
KIND TO LINGER ON
SURFACES. ABSORPTION
CAUSES THE WOOD TO
WARP AND THE FINISH
TO DE-LAMINATE.

DO NOT USE
COMMERCIAL
POLISHES
AND WAXES



**PREVENT
YELLOWING**

DO NOT
PLACE HOT
POTS, ETC.
ON
SURFACE



**PREVENT
DAMAGE TO
FINISH!**

REGULATE
THE
HUMIDITY
CONDITIONS
AT YOUR
HOME




**PREVENT
SPLITTING**

ASSEMBLY INSTRUCTIONS

DO NOT FULLY TIGHTEN ALL HEX BOLTS UNTIL THE ENTIRE UNIT IS COMPLETELY ASSEMBLED


Step 1: Place the Server (A) upside down on a piece of cloth or carpet to prevent finish from scratching. Attach Metal Leg (B) to the Server (A) by inserting Hex Bolt (1), Flat Washer (3), Lock Washer (2) and fully tighten with Wrench (4). Do not over tighten .



Step 2: Turn the Server to upright position. (**Note: It is recommended to use two or more people to turn the Server*). Place the Server on flat surface and adjust the Leveler under the Metal Legs (B) until level and does not wobble.


- Open the Doors, remove the Handles by unfasten the Handle's Bolts and attach it to the outside of the Doors by using Phillips-head screwdriver (not provided) as the picture shown.

- The Tipping Restraint (5) is stapled at the back of Server (A). Thread Tipping Restraint (5) through the slots of the Server (A) to fasten and lock as the picture shown. Assembly of product is now completed.




PART LIST






(A) SERVER
(1PC)




(B) METAL LEG
(2PCS)



HARDWARE PACK # : PYS500SVH

NO.	DESCRIPTION		DIMENSION	Q'TY
1	Hex Bolt		$\Phi \frac{1}{4}" \times 25 \text{ mm}$	8 pcs
2	Lock Washer		$\Phi \frac{5}{16}" \times 13 \text{ mm}$	8 pcs
3	Flat Washer		$\Phi \frac{5}{16}" \times 19 \text{ mm}$	8 pcs
4	Wrench		12 mm	1 pc
5	Tipping Restriant			1 set

PARTS FOR YS500SV **COMPLETE HARDWARE # : PYS500SVH**



PRODUCT DETAILS

TOP	MDF / ASH VENEER
APRON	MDF / ASH VENEER/ MANGO WOOD
DOOR	MANGO WOOD / TEMPERED GLASS
SHELF	MDF / LOCAL VENEER
WINE RACK	MDF / LOCAL VENEER
LEG	METAL
PRODUCT SIZE	60" x 18" x 36" H
CARTON SIZE	62.79" x 20.87" x 34.84" H
NET WEIGHT	155.1 LBS
GROSS WEIGHT	173.8 LBS
CU.FT.	26.42'

MADE IN VIETNAM