

## ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

### 708158 COFFEE TABLE

REVISION 0: 12/14/2023

PAGE 1 OF 7

COASTERFURNITURE.COM

# ITEM:708158 ASSEMBLY INSTRUCTIONS



COASTERFURNITURE.COM


### **ASSEMBLY TIPS:**

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



#### **WARNING!**

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME 35 MINUTES

### PARTS IDENTIFICATION

TOP 1PC В **SHELF** 1PC TOP CROSSBAR 2PCS C D **BOTTOM CROSSBAR** 2PCS Ε LEG<sub>1</sub> 2PCS

PAGE 2 OF 7

# ITEM:708158 ASSEMBLY INSTRUCTIONS PARTS IDENTIFICATION



F LEG 2 2PCS

G BOTTOM SUPPORT CROSSBAR 1PC

H TOP SUPPORT CROSSBAR 2PCS

## ITEM:708158

### **ASSEMBLY INSTRUCTIONS**



Ζ

### HARDWARE IDENTIFICATION

SHORT BOLT (1/4" x 12mm SR)

24PCS

5 SCREW (4 x 25mm SR)



2PCS

2 MEDIUM BOLT (1/4" x 22mm SR)



8PCS

6 WASHER



4PCS

3 CAP



4PCS

7 ALLEN WRENCH (4mm)



1PC


4 LONG BOLT (1/4" x 47mm SR)





2PCS


STEP 1


Do not tighten until each step is completed or instructed.











### ITEM:708158 ASSEMBLY INSTRUCTIONS



Product Size: 1207 X 597 X 495~737 H (MM)

Product Size: 47.5" X 23.5" X 19.5"~29"

