

FM80002NT-CH-4PK FM80002NT-CH-2PK FM80002BB-CH-4PK FM80002BB-CH-2PK





ASSEMBLY INSTRUCTIONS OUTDOOR CHAIR

PARTS Check that you've received all parts listed below.



2











M6x30 mm 4 pcs

1 pc









A x 4

B x 1

F

STEP 1









Need some help?



1-888-980-5122









Outdoor furniture naturally weathers and shows color variation over time. We recommend the following care for the best results:

- Wipe with a soft cloth.
- Wash with mild soap and water as needed; do not use abrasive cleaners.
- Cover furniture with an outdoor cover (not included) when not in use.
- Store in a dry, covered area during inclement weather or winter season.



After assembly is completed, save these instructions and any included tools for future maintenance or re-assembly.