

# ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

710577 <u>End Table</u>



#### **ASSEMBLY INSTRUCTIONS**

#### **ASSEMBLY TIPS:**

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



#### **WARNING!**

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.







### PARTS IDENTIFICATION

A TOP



1PC

B LEG



4PCS


### HARDWARE IDENTIFICATION


1	(Ø1/4" x 2" - BLK)	8PCS
2	LOCK WASHER (1/4" x 16mm - BLK)	8PCS
3	FLAT WASHER (Ø1/4" - BLK)	8PCS
4	ALLEN WRENCH	1PC

#### **ASSEMBLY INSTRUCTIONS**



## STEP 1







#### **ASSEMBLY INSTRUCTIONS**

## STEP 3







#### **ASSEMBLY INSTRUCTIONS**

# COASTER FINE FURNITURE


# STEP 5 COMPLETE







Inner Size of Drawer : 15.00"W x 15.00"D X 4.00"H X 0.25"T



Note: Dimension tolerance ± 5%



# ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

710578 Coffee Table



#### **ASSEMBLY INSTRUCTIONS**

#### **ASSEMBLY TIPS:**

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



#### **WARNING!**

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.







#### PARTS IDENTIFICATION

A TOP 1PC

B LEG 4PCS

C BOTTOM SHELF 1PC

D CASTER 4PCS


### HARDWARE IDENTIFICATION


1	LONG BOLT (Ø1/4" x 2" - BLK)	12PCS
2	SHORT BOLT (Ø1/4" x 1-1/4" - BLK)	8PCS
3	LOCK WASHER (1/4 x 16mm - BLK)	20PCS
4	FLAT WASHER (Ø1/4" - BLK)	20PCS
6	ALLEN WRENCH (4mm - BLK)	1PC

#### **ASSEMBLY INSTRUCTIONS**

# COASTER FINE FURNITURE

## STEP 1







#### **ASSEMBLY INSTRUCTIONS**

# COASTER FINE FURNITURE

## STEP 3







#### **ASSEMBLY INSTRUCTIONS**

## STEP 5









#### **ASSEMBLY INSTRUCTIONS**

# COASTER

### STEP 7






#### **ASSEMBLY INSTRUCTIONS**

# COASTER FINE FURNITURE


# STEP 9 COMPLETE







Inner Size of Drawer: 17.75"W x 24.75"D X 3.25"H X 0.25"T



Note: Dimension tolerance ± 5%