


ASSEMBLY INSTRUCTION FOR DINING TABLE WITH 1X18" LEAF D-3720-8-DT

Caution:Please read instructions thoroughly before unpacking assembly parts. Sharp, exposed staple tips can cause injury, therefore, for your protection, please remove any exposed staples used in packing.


- 1.We recommend that you should assemble this product with the assistance of another person; this will make assembly easier, and will help to eliminate damage to the product or injury to persons during assembly.
- 2.Be sure to check all packing materials carefully for small parts that may have come loose inside the carton during shipment.
- 3.Please do not over tighten screws or bolts.
- 4.Please put all parts on a non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.

PARTS LIST				HARDWARE LIST				
NO.	PART DESC		Q'TY	NO.	HARDWARE DESC		Q'TY	
A	Table top		1pc	1		Allen bolt (Ø5/16"*1-7/9")	PD-3720-DTHW	4pcs
				2		Allen bolt (Ø5/16"*3-5/9")		8pcs
B	Leaf		1pc	3		Spring washer (Ø5/16")		12pcs
				4		Flat washer (Ø5/16")		12pcs
C	Legs		2pcs	5		Allen key (M4)		1pc
				6		Dowel (Ø2/5"*1-1/6")		4pcs
						SCREW-DRIVER(NOT PROVIDED)		




Only tighten all bolts when all bolts aligned with bolt inserts.

STEP: 1




STEP: 2




ASSEMBLY INSTRUCTION FOR DINING TABLE WITH 1X18" LEAF D-3720-8-DT


STEP: 3




STEP: 4




STEP: 5



STEP: 6



STEP: 7



Assembly Completed

