


Assembly Instruction for




END TABLE CTKM800ET/CTKM800ETE

Caution: Please read instructions thoroughly before unpacking assembly parts. Sharp, exposed staple tips can cause injury, therefore, for your protection, please remove any exposed staples used in packing.

1. We recommend that you should assemble this product with the assistance of another person; this will make assembly easier, and will help to eliminate damage the product or injury to persons during assembly.
2. Be sure to check all packing materials carefully for small parts that may have come loose inside the carton during shipment.
3. Please do not over tighten screws or bolts .
4. Please put all parts on a non - abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.

PARTS LIST			
No	PARTS DESC.	CODE.	Q'TY.
A	 TOP	PCTKM800ETTOP	1PC
B	 FRAME LEG 1	PCTKM800ETLEG 1	1PC
C	 FRAME LEG 2	PCTKM800ETLEG 2	1PC
D	 L/R STRETCHER	PCTKM800ETSTR	2PCS

HARDWARE LIST			
No	HARDWARE DESC.		Q'TY.
1	 BOLT 1/4"x 38mm	PCTKM800ETHW	7PCS
2	 SPRING WASHER Ø1/4"		7PCS
3	 FLAT WASHER Ø1/4" Ø19x2mm		7PCS
4	 ALLEN KEY 2-1/4"x4mm		1PC



Assembly completed