



Assembly


Stressless® Emily




Scan me for instruction




STRESSLESS® EMILY INDEX




STRESSLESS® EMILY
1 Seat Power/Dummy **Page 5**




STRESSLESS® EMILY
End Module **Page 13**
Center Module **Page 14**




STRESSLESS® EMILY
LongSeat Large **Page 20**





STRESSLESS® EMILY
Corner **Page 9**



STRESSLESS® EMILY
LongSeat Medium **Page 15**




STRESSLESS® EMILY
1 Seat Angled **Page 25**




STRESSLESS® EMILY
Battery Pack **Page 30**


STRESSLESS® EMILY MODULES




1s
w/arm left




1s
wo/arms




1s
w/arm right




Angled module
w/arm left



Angled module
wo/arms



Angled module
w/arm right



Corner




1s Power
w/arm left




1s Power
wo/arms



1s Power
w/arm right



Longseat
(M) arm left




Longseat
(M) arm right




Longseat
(L) arm left




Longseat
(L) arm right



Center
module




End module
left



End module
right



Arm Steel



Arm Wide




Arm Wood

POWER SUPPLY PLACEMENT





EN	CAUTION: Maximum seats per Power supply unit = 3. Battery placement only on modules with Power supply.
NO	OBS: Maksimalt antall motoriserte seter per strømforsyning = 3. Batteri skal bare kobles til moduler med strømforsyning.
SV	VARNING: Maximalt antal motoriserade platser per strömförsörjningsenhet = 3. Batteri placering endast på moduler med strömförsörjning.
DK	OBS: Maksimalt antal motoriseret sæder pr. strømforsyning er 3. Batteri skal kun tilkobles moduler med strømforsyning.
FIN	HUOM: Moottoroitujen istuimien enimmäismäärä virtalähdettä kohti = 3. Akun saa kytkeä vain moduuleihin, joissa on virtalähde.
DE	ACHTUNG: Maximal 3 Sitzelemente pro Netzteil! Platzierung des Akkus nur bei Modulen mit Netzteil.
NL	LET OP: Maximaal aantal Power zitplaatsen per transformator = 3. Installatie van de batterij alleen op met transformator uitgeruste module(s).
FR	ATTENTION : Nombre maximum de places Power par transformateur = 3. Installation de la batterie uniquement sur le(s) module(s) équipé(s) de transformateur.
IT	ATTENZIONE: Numero massimo di posti Power per trasformatore = 3. Installazione della batteria solo su moduli dotati di trasformatore.
ES	OJO: Número máximo de plazas Power (motorizadas) por transformador = 3. Instalación de la batería solo en módulos equipados con transformadores.
PT	CUIDADO: Máximo de lugares por unidade de fonte de alimentação = 3. Colocação da bateria apenas em módulos com fonte de alimentação.
JA	注意: 電源モーター1個あたりの接続可能最大座席数 = 3。 バッテリーは電動モーター式モジュールにのみ設置可。
ZH	注意: 每个电源装置最多支持3个椅位; 电池仅内置于带有电源装置的沙发模块中。
KR	주의: 전원 공급 장치당 최대 시트 수 = 3 전원 공급 장치가 있는 모듈에만 배터리 배치
TW	注意: 每個電源裝置的最大席位數 = 3。電池只能放置在帶电源的模組上。
IN	सावधान: प्रतपावर सप्लाय युनिट अधिकतम सीट = 3। बैटरी को केवल बजिली की आपूर्ति वाले मॉड्यूल पर लगाए।








→ = Power Connections

STRESSLESS® EMILY 1 SEAT POWER / DUMMY




1997498






8





STRESSLESS® EMILY CORNER







Ø 4.2 cm
8 cm/3.15 inch
6x 1997508


1




If battery, assemble battery pack on modules with power supply



6



7



Stressless® Emily - 12

STRESSLESS® EMILY END MODULE






Chrome 1997394
Black 1997395




2x 1997016




Ø 4.2 cm
12.5 cm/4.92 inch
2x 1997826





STRESSLESS® EMILY STEEL



Ø 4.2 cm
12.5 cm/4.92 inch
2x 19978XX




Ø 4.2 cm
12.5 cm/4.92 inch
2x 1997826





STRESSLESS® EMILY WOOD



Ø 6 cm
12.5 cm/4.92 inch
2x 1997820




Ø 4.2 cm
12.5 cm/4.92 inch
2x 1997826






STRESSLESS® EMILY WIDE

Stressless® Emily - 13


STRESSLESS® EMILY CENTER MODULE




STRESSLESS® EMILY LONG SEAT MEDIUM




STRESSLESS® EMILY LONGSEAT MEDIUM LEG PLACEMENT



STRESSLESS® EMILY STEEL




STRESSLESS® EMILY WOOD




STRESSLESS® EMILY WIDE

If battery, assemble battery pack on modules with power supply


5




6




7




8





9




10




STRESSLESS® EMILY LONG SEAT LARGE




STRESSLESS® EMILY LONGSEAT LARGE LEG PLACEMENT



STRESSLESS® EMILY STEEL









STRESSLESS® EMILY WOOD




STRESSLESS® EMILY WIDE


If battery, assemble battery pack on modules with power supply



10



STRESSLESS® EMILY 1 SEAT ANGLED



Ø 4.2 cm
8 cm/3.15 inch
4x 1997508




2x 1997543




4x 1997721


1



2




3




If battery, assemble battery pack on modules with power supply



4





5




6





1997498





7





8



9






10




BATTERY PACK

1997548

Available for all modules with Power supply unit.



WARNING





STRESSLESS.COM

Ekornes AS, Industrivegen 1, N-6222 Ikornes

Tel.: (+47) 70 25 52 00

E-mail: office.no@ekornes.com