

CROSLEY FURNITURE


Counter Stool CF502926



PART LIST



HARDWARE LIST



ADDITIONAL TOOLS (Not Provided)


Note: It is not recommended to use power tools during assembly.




Phillips Head Screwdriver

Step 1 . Carefully turn seat frame (part B) upside down on a flat, soft surface, such as carpet. Attach left front leg (part C), front stretcher (part G) and right front leg (part D) to seat frame (part B) using medium bolts (part #2), spring washers (part #4), flat washers (part #5) and allen wrench (part #7).

NOTE: Please do not fully tighten bolts until unit is fully assembled.




Step 2 . Attach seat frame (part B), left stretcher (part E) and right stretcher (part F) to back frame (part A) using short bolts (part #3), spring washers (part #4), flat washers (part #5) and allen wrench (part #7).



Step 3. Secure corners on seat frame (part B) to back frame (part A) using long bolts (part #1), spring washers (part #4), flat washers (part #5) and allen wrench (part #7).

NOTE: Please do not fully tighten bolts until unit is fully assembled.



Step 4. Insert screws (part #6) into the holes of front stretcher (part G), left stretcher (part E) and right stretcher (part F) then tighten using phillips head screwdriver.

NOTE: Please fully tighten all bolts at this time.

