MODEL #

ASSEMBLY INSTRUCTIONS

FM47008WH-CS

TOOLS REQUIRED





2 - People

ASSEMBLY RATING



EASY ⟶ DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.

CHECK BEFORE STARTING

- [ ] **Are you missing anything?**

  Double-check all parts, hardware and accessories listed are all acccounted for.

- [ ] **Should we send any replacements?**

  Are there any irregularities or flaws in the parts? We can send replacements!

- [ ] **Check out our Quick Tips!**


  We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!

- [ ] **Prep Time!**

  Please review the assembly instructions and all diagrams prior to assembling.


PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.



Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.



Suitable Location

Assembling near the area of the intended location is highly recommended.




Sufficient Space

Make sure you have enough space to move around during the assembly.



Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent to prevent scratches and damages.



Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

SAFETY INFORMATION (CONTINUED)

FCC STATEMENT

This equipment has been tested and found to comply with the limits for a Class B digital device pursuant to Part 15 of the FCC Rules.
These limits are designed to provide reasonable protection against harmful interfer
installation. This equipment generates, uses, and can radiate radio frequency ener
and used in accordance with the instructions, may cause harmful interference to r
wever, there is no guarantee that interference will not occur in a particular installation. If this equip
does cause harmful interference to radio or television reception, which can be deter
equipment off and on, the user is encouraged to try to correct the interference b
wing measures:

Reorient or relocate the receiving antenna.
ease the separation between the equipment and the receiver.
onnect the equipment into an outlet on a circuit different from that to whic
onsult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the follo
conditions:

This device may not cause harmful interference, and

This device must accept any interference received, including interfer
ed operation.

CAUTION: Changes or modifications not expressly approved by the party r
compliance could void user's authority to operate the equipment.

ITEM: FM47008WH-CS


ASSEMBLY INSTRUCTIONS

WARNING! The mirror part provided in this package is not a tempered mirror. Please handle with care. Mirror part may explode.

Press to turn on/off the lights.

Press to turn on /off the bluetooth

Wireless charging for mobile phones



ASSEMBLY COMPLETED


Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.

Keep this handy!

Please retain this instruction manual and any order-related information for future reference.

Lift, don't drag!

To avoid damage to product please always LIFT the product when transporting of adjusting the placement.




This product is intended for RESIDENTIAL USE ONLY and not for commercial use.

Bluetooth Speaker Instruction:

CONTROL PANEL MENU:



ON/OFF



Bluetooth speaker



interface of DC in



Voice

INSTRUCTION STEPS AS FOLLOWED:

1. Connect the DC-IN power adapter to wall socket
2. Turn the switch ON
3. Enable the bluetooth function in your digital device
4. Search for bluetooth speaker name“BT- JMK”
5. Pair with the bluetooth speaker name“BT- JMK”
6. Start playing your audio