

Thank you for purchasing this quality product. Be sure to check all packing materials carefully for small parts, which may have come loose during shipment. Identify and count all items and compare with the parts list shown below. It is recommended to have two people during assembling and to remove the back and base of the furniture out from the box. **Please follow the drawings below to assemble the item**

PARTS LIST			
NO.	DESCRIPTION	SKETCH	QTY
A	Seat		1PC
В	Left Side Facing (LSF) Backrest		1PC
С	Mid backrest		1PC
D	Right Side Facing (RSF) Backrest		1PC
E	Power Cable 29V		1PC

WEIGHT CAPACITY(PER SEAT)

350 LBS


All images shown are for illustration purpose only. Actual product may vary due to product enhancement.



ASSEMBLY INSTRUCTIONS CHESTER COLLECTION ITEM#: U5483-30P2 DESCRIPTION : CHESTER RECLINING SOFA W/PWR HR & FR


Step 1:

Insert the backrests(B/C/D) to the seat (A) and make sure the backrests are secured in position.



Step 2:


Connect the cable on the backrests (B & D) to the cables on the seat (A).



All images shown are for illustration purpose only. Actual product may vary due to product enhancement.



ASSEMBLY INSTRUCTIONS CHESTER COLLECTION **ITEM#:** U5483-30P2 **DESCRIPTION** : CHESTER RECLINING SOFA W/PWR HR & FR





ASSEMBLY INSTRUCTIONS CHESTER COLLECTION ITEM#: U5483-30P2 DESCRIPTION : CHESTER RECLINING SOFA W/PWR HR & FR

Step 5: Connect the power and open/close the footrest and headrest by pressing the power buttons.

