

## Specs

### Play:5 Audio



**Six Class-D digital amplifiers** perfectly tuned to match the six dedicated speaker drivers and the acoustic architecture.



**Three tweeters** create the crispest and clearest high-frequency response.



**Three mid-woofers** ensure you'll hear the faithful playback of mid-range vocal frequencies plus deep, rich bass—without distortion, even at high volumes.

**Phased speaker array** (three drivers on top and three on the bottom) creates a wide stereo soundstage that directs the sound left, right, and center.



**Audio line-in.** An auto-detecting 3.5 mm connection.



**Adjustable bass and treble controls** let you customize your sound by individual room or groups of rooms.

### Play:5 Physical



#### Dimensions - H x W x D

8.03 x 14.33 x 6.06 in. (203 x 364 x 154 mm).



#### Weight

14 lbs. (6.36 kg).



#### Product finish

White or black matte enclosure with graphite grille.



#### Touch-interface controls & lights

Capacitive touch controls for volume up/down, previous/next track, and play/pause. LED indicates Sonos component status and mute status.

### Power & Networking



#### Power supply

Auto-switching 100-240 V, 50-60 Hz AC universal input.



#### WiFi, not Bluetooth

Connects to your home WiFi network with any 802.11b/g, 2.4 GHz broadcast-capable router for uninterrupted wireless streaming.



#### Ethernet port

One 10/100 Mbps Ethernet port. Wire directly to your router to operate your Sonos if WiFi is unstable, or use the Ethernet port to provide Internet accessibility to non-wireless devices if you're using Boost setup.

### Play:5 Contents



Sonos Play:5, power cord, Ethernet cable, Sonos QuickStart Guide, and Legal/Warranty information.