

McKenzie Occasional Table

GAC = Glazed Antique Cherry finish

CAF = Caffè finish


Assembly Instructions

Model #

3497GACa

3497CAFa


McKenzie Accent Table



3498GACa

3498CAFa

McKenzie Side Table



IMPORTANT NOTES:

- For normal household use only. *Not* recommended for commercial use.
- Do not climb, sit, or stand on this piece of furniture.
- Unload items before you move this unit.
- Do not overload the shelves.

WARNING

Drilling, sawing, sanding or machining wood products can expose you to wood dust, a substance known to the state of California to cause cancer. Avoid inhaling wood dust or use a dust mask or other safeguards for personal protection.

For more information go to: www.p65warnings.ca.gov/wood

This product can expose you to chemicals, including formaldehyde, which are known to the State of California to cause cancer.

For more information go to: www.p65warnings.ca.gov/furniture

DESIGN SUBJECT TO CHANGE WITHOUT NOTICE.

Thank you for allowing us to help you furnish your home. We are certain you will be delighted with your new furniture for many years to come.

CUSTOMER SERVICE

If you ever have questions about your furniture, please do not hesitate to contact us. In the unlikely event you need a replacement part; we can make those parts available through an authorized Whittier Wood Furniture dealer. If you cannot order replacement parts through your dealer, please contact our customer service department.

Hours: Our friendly customer service staff can be reached:

Monday-Friday 8:00 a.m. to 5:00 p.m. (Pacific Time).

You may leave a message 24 hours a day, seven days a week.

Customer Service: 800-653-3336 • Outside the U.S.: 541-687-0213

Fax: 541-687-2060 • Email: info@whittierwood.com

**Whittier
Wood**

FURNITURE

P.O. Box 2827
Eugene, OR 97402 USA

Production Code:













VN

12/19

3497GACa 3497CAFa McKenzie Accent Table
3498GACa 3498CAFa McKenzie Side Table

Parts List

Please identify the parts and check that quantities received match those on this list.
 If you need to replace a part, refer to the following letter and part name.


Part	Description	Quantity
Aa	Top Assembly 	1
B	Leg 	4
C	Shelf Assembly 	1
D	#8 x 1-1/4" Pan Head Screw 	30 (22 inserted)
E	5/16" Flat Washer 	4
F	3/8" x 2-1/2" Hex Bolt 	4
H	3/8" x 1" Insert Nut (inserted) 	4
J	Adjustable Glide (installed) 	4
K	Wood Dowel (inserted) 	4
L	1/4" x 20mm Insert Nut (inserted) 	4
M	#8 x 1-3/8" Lo-Profile Screw (inserted) 	4
N	#8 Washer (inserted) 	6

3497 shown in the illustrations.


3497GACa 3497CAFa McKenzie Accent Table
3498GACa 3498CAFa McKenzie Side Table
Assembly Instructions

Tools Required: Phillips Screwdriver, 9/16" or Adjustable Wrench

1. Turn the Top Assembly (Aa) upside-down on a clean, protected surface. Position the Legs (B) in the corners so the Insert Nuts (H) face in. LOOSELY attach with four 5/16" Flat Washers (E) and four 3/8" x 2-1/2" Hex Bolts (F) (the legs should be wobbly). See Figures 1 and 1a.




2. Turn the Shelf Assembly (C) upside-down and place the dowels into the dowel holes in the Legs. Tighten the Hex Bolts on the Legs. See Figure 2.



3497GACa 3497CAFa McKenzie Accent Table
3498GACa 3498CAFa McKenzie Side Table
Assembly Instructions

3. Using the pocket holes as guides, secure the Shelf (C) to the Legs (B) with eight #8 x 1-1/4" Pan Head Screws (D). See Figures 3 and 3a.



4. Turn the table upright and place the table at its final destination. To level the table, rotate the Adjustable Glides (J) found on the bottoms of the legs.

