

ASSEMBLY INSTRUCTIONS

MODEL

FM7202-Q

Questions?

GIVE US A CALL: 1-888-980-5122 MON-FRI 8:30AM - 5:30PM (PT)

TOOLS REQUIRED



Screwdriver (Not included)



Allen Wrench



2 - People

ASSEMBLY RATING



The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.





Thank you for your purchase!

We hope you enjoy this new addition to your home for many years to come.

Our commitment to providing quality products does not simply end when you purchase our product. We fully stand behind our products from start to finish. Our customer service department is available Monday – Friday 8:30 AM – 5:30 PM Pacific Time and can help with assembly questions as well as, if necessary, replacing damaged or missing parts. To help expedite our service, please have these assembly instructions readily available, along with your order receipt.



CHECK BEFORE STARTING

	Are you missing anything?	Check out our Quick Tips!
	Double-check all parts, hardware and accessories listed are all acccounted for.	We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!
	Should we send any replacements?	Prep Time!
	Are there any irregularities or flaws in the parts? We can send replacements!	Please review the assembly instructions and all diagrams prior to assembling.

PRE ASSEMBLY

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.











ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.

Suitable Location

Sufficient Space

Assembling near the area of the intended location is highly recommended.





ŝ.





Make sure you have enough space to move around during the assembly.

Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent to prevent scratches and damages.

Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

ASSEMBLY AND **CARE ADVICE**



FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY, THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.



FM7202-Q is packed in 3 cartons

CARTON	DESCRIPTION	PART	HARDWARE
FM7202-Q-HB	QUEEN HEADBOARD	1 x1	A x 12 PCS
	QUEEN HB - LEG LEFT	2 x1	 B x 12 PCS C x 12 PCS
	QUEEN HB - LEG RIGHT	3 x1	D x 1 PC
	QUEEN STRETCHER	(4) — x1	F x 4 PCS
	QUEEN STRETCHER - X	(5) >>> x1	
FM7202-Q-FB	QUEEN FOOTBOARD	6 x1	G x 8 PCS
	QUEEN SLAT	7 ×4	H x 8 PCS I x 1 PC
	QUEEN VERTICAL	(8) € x8	J x 8 PCS
FM7202-R	QUEEN / KING SIDE RAIL	9 x2	

ASSEMBLY INSTRUCTIONS

Use Allen Key (#D) to attach HB-Leg Right (#2) / Left (#3) Part(1)1pc to Headboard (#1) by using (:]Part (2) 1pc Bolt (#A) with lock washer A Part 3 1pc (#B) and flat washer (#C). 2 Hardware A 8pcs Hardware (B) 8pcs Hardware C 8pcs D Hardware (D) 1pc В 3 1 Using Panhead Screw (#F) to attach Stretcher – X (#5) to Headboard (#1), tighten with Screw Driver. F 4 В Part (4) 1pc R Part (5) 1pc Α 5 Hardware (A) 4pcs Hardware B 4pcs D Hardware C 4pcs Hardware (D) 1pc Hardware (F) 4pcs С Use Allen Key (#D) to attach Stretcher (#4) to Headboard (#1) by using Bolt (#A) with lock washer (#B) and flat washer (#C).

ASSEMBLY INSTRUCTIONS

