



# Assembly Instruction for





60" COUNTER SET

D.530.C7PC

Caution: Please read instructions thoroughly before unpacking assembly parts. Sharp, exposed staple tips can cause injury, therefore, for your protection, please remove any exposed staples used in packing.


1. We recommend that you should assemble this product with the assistance of another person; this will make assembly easier, and will help to eliminate damage the product or injury to persons during assembly.
2. Be sure to check all packing materials carefully for small parts that may have come loose inside the carton during shipment.
3. Please do not over tighten screws or bolts .
4. Please put all parts on a non - abrasive oor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and eiciently.

PARTS LIST FOR TABLE			
No	PARTS DESC.	CODE.	Q'TY.
A	 TOP TABLE		1
B	 LEG	PD.530.DTLEG PD.530.CTLEG	4

HARDWARE LIST FOR TABLE			
No	HARDWARE DESC.		Q'TY.
1		HEX NUT ( 5/16")	8
2		SPRING WASHER Ø5/16"	8
3		FLAT WASHER Ø5/16" (Ø19mm)	8
4		Ø5/16" WRENCH (12mm)	1

NOTE : Do not fully tighten any bolts until last step.

## STEP 1










# Assembly Instruction for








60" COUNTER SET

D.530.C7PC

Caution: Please read instructions thoroughly before unpacking assembly parts. Sharp, exposed staple tips can cause injury, therefore, for your protection, please remove any exposed staples used in packing.

1. We recommend that you should assemble this product with the assistance of another person; this will make assembly easier, and will help to eliminate damage the product or injury to persons during assembly.
2. Be sure to check all packing materials carefully for small parts that may have come loose inside the carton during shipment.
3. Please do not over tighten screws or bolts .
4. Please put all parts on a non - abrasive oor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and eciently.

PARTS LIST COUNTER CHAIR			
No	PARTS DESC.	CODE.	Q'TY.
A	 BACK FRAME	PD.530.CSCBFR	1
B	 SEAT	PD.530.SCSEC	1
C	 LEFT FRONT LEGS	PD.530.CSCLEG	1
D	 RIGHT FRONT LEGS		1
L	 LEFT STRETCHER	PD.530.CSCSTR2	1
R	 RIGHT STRETCHER		1
F	 FRONT STRETCHER	PD.530.CSCSTR1	1

HARDWARE LIST FOR COUNTER CHAIR			
No	HARDWARE DESC.		Q'TY.
1		ALLEN BOLT( 1/4"x 53mm)	4
2		ALLEN BOLT( 1/4"x 35mm)	3
3		ALLEN BOLT( 1/4"x 85mm)	4
4		SPRING WASHER Ø1/4"	11
5		FLAT WASHER Ø1/4"	11
6		ALLEN KEY	1
7		SCREW (#35mm)	6


TOOLS REQUIRED (NOT PROVIDED)



PHILLIPS SCREW DRIVER

NOTE : Do not fully tighten any bolts until last step.

## STEP 1





# Assembly Instruction for

60" COUNTER SET

D.530.C7PC

## STEP 2



COMPLETED