













Components and Hardware List

Top Assembly  (A) 1 pc.	Side Frame  (B) 2 pcs.	Center Frame  (C) 1 pc.	 #12050 Rectangle Dining Table	
M5/16" x 1-1/2" Allen Head Bolt  (D) 6 pcs.	M5/16" x 4-1/2" All-Thread Bolt  (E) 4 pcs.	5/16"x12*3mm Spring Washer  (F) 10 pcs.	5/16" x 19*2mm Flat Washer  (G) 6 pcs.	Ø5/16" x 12 Hex Nut  (H) 4 pcs.
Curved Washer 32L x 13 x 8mm  (I) 4 pcs.	5mm Allen Key  (J) 1 pc.	12mm Open Wrench  (K) 1 pc.		

Be sure to check all packing material carefully for small parts, which may have come loose inside the carton during shipment.





To position the table top extensions, grab the extension by the finger grooves located under each extension and pull outward until the extension stops, lift the extension upward until the top surfaces are level, push inward until there is no gap between the top and extension.