






Assembly Instructions  
DINING TABLE  
DDV100DTT / DDV100DTB

- Caution: Please read instructions thoroughly before unpacking assembly parts. Sharp, exposed staple tips can cause injury, therefore, for your protection, please remove any exposed staples used in packing.
1. We recommend that you should assemble this product with the assistance of another person; this will make assembly easier, and will help to eliminate damage to the product or injury to persons during assembly.
  2. Be sure to check all packing materials carefully for small parts that may have come loose inside the carton during shipment.
  3. Please do not over tighten screws or bolts.
  4. Please put all parts on a non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.


PART LIST FOR DINING TABLE			
No.	PART DESC	CODE.	Q'TY
A	Dining Table Top Dark - Top		1
B	Dining Table Top Dark - Leaf		1
C	Dining Table Top Dark - Base		
D	Dining Table Top Dark - Top Connecting Panel	PDDV100DTTTOP	2
E	Dining Table Top Dark - Leaf Support Rail	PDDV100DTTLEA	2

HARDWARE LIST			
No.	HARDWARE DESC	CODE.	Q'TY
1	 ALLEN BOLT (5/16" x 45mm)	PDDV100DTTHW	24
2	 SPRING WASHER (5/16")		24
3	 FLAT WASHER (5/16")		24
4	 ALLEN KEY M4		1


STEP:1



STEP:2




STEP:3



Assembly Instructions  
DINING TABLE  
DDV100DTT / DDV100DTB

STEP:4



STEP:5

