

# **LINKSWELL GEN IV SETUP GUIDE**




**FORD, RAM,  
GMC/CHEVY, &  
TUNDRA RADIOS**

# TABLE OF CONTENTS



1. General Settings
2. General Settings (Continued)
3. Audio Settings
4. Audio Volume Settings
5. EQ Settings
6. Fade & Balance Settings
7. Video Settings (HDMI OUTPUT)
8. User Settings
  - a. Navigation, Bootlogo, Custom AppList
9. Custom AppList (Continued)
10. Setting your Navigation App
11. Vehicle Setup, Wi-Fi, & Updates
12. Android Settings & Factory Reset
13. Setup Guide
  - a. Air Conditioning Settings
  - b. Heated & Cooled Seat Settings
  - c. 360 Camera Settings (FORD)
14. Setup Guide (Continued)
  - a. Factory Amplifier
  - b. Reverse Mute Settings
  - c. Parking Guidelines
  - d. Reverse & Front Proximity Sensor Audio
15. Setup Guide (Continued)
  - a. Steering Wheel Control SEEK Buttons
  - b. Ambient Lighting ON/OFF (FORD)
16. Extra Tips and Tricks
17. Ford Truck Climate Control Setup
18. GMC/Chevy Truck Climate Control Setup
19. RAM Truck Climate Control Setup
20. Tundra Truck Climate Control Setup
21. More information & Tech Support



# GENERAL SETTINGS


Time: Set the Time, Time Zone, and Daylight Savings Time

Dimmer: Set the Screen Brightness during the Day and Night

Beep: Enable/Disable the Touch Tone

Antenna Power: Activate the Powered FM Antenna Wire

Language: Choose system Language




# GENERAL SETTINGS

Units: Change Temperature from US/Imperial to EU/Metric

Radio Region: Change FM Radio Frequency by Country

RDS: Enable/Disable RDS (Radio Data System)



# AUDIO SETTINGS


Equalizer: View Equalizer Settings (See page 5)

MIC Gain: Change Microphone Gain settings (Echo Reduction)

Radio: Change the FM/AM Radio volume

Music: Change the Music volume

Video: Change the Video volume



# AUDIO SETTINGS


BT: Change the Bluetooth Phone Call volume

BT-Music: Change the Bluetooth Music volume

AUX: Change the AUX Input volume

Navi Volume: Change the Navigation voice volume

Others: Change all other volume options



# AUDIO SETTINGS

Sound: Change EQ Sound Options

Balance: Change Balance & Fader (See page 5)

Treble: Change Treble volume/gain

10kHz\*: Change Treble Frequency

Midrange: Change Midrange volume/gain

1kHz\*: Change Midrange Frequency


Bass: Change Bass volume/gain

80Hz\*: Change Bass Frequency

Sub-woofer: Change Subwoofer RCA output Volume

EQ: Change EQ Preset


\*Frequency numbers may change while altering settings



# AUDIO SETTINGS

Loudness: Enable "Loudness" mode

Reset: Reset EQ to Default Settings




# VIDEO SETTINGS

HDMI Output Type: Change HDMI Output Mode

Video: HDMI OUTPUT will output any video playing on the Radio

Full Screen: HDMI OUTPUT will output the entire screen as a "Screen Mirror"



# USER SETTINGS


Navi Customize: Set the “Navigation” icon’s Application

Boot Logo: Set the Radio’s startup boot image

Music: Change the Music app (Home Screen)

Video: Change the Video app (Home Screen)

(See Page 9 for APP1, APP2, APP3, etc)



# USER SETTINGS

APP1: Set the first app in the custom home-bar

APP2: Set the second app in the custom home-bar


APP3: Set the third app in the custom home-bar

APP4: Set the fourth app in the custom home-bar

APP5: Set the fifth app in the custom home-bar

APP6: Set the sixth app in the custom home-bar


APP7: Set the seventh app in the custom home-bar



# USER SETTINGS

When you select Navi Customize:

App Customize: Any application installed on the radio can be chosen in this menu. This application will be your “Navigation” app.



# SYSTEM SETTINGS


Setting Guide: Vehicle Setup (See page 13)

Network: Connect the Radio to Wi-Fi

GPS: Check GPS Signals

Software Version: View current Software info

Upgrade: Check for System Updates (Wi-Fi Only)




# SYSTEM SETTINGS

Android Settings: View the internal Android Settings menu

Factory Settings: View Developer/Linkswell settings

Factory Reset: Reset basic radio settings



# SYSTEM SETTINGS


For info how to get to this menu, check page 11.

Car Model/AC: Setup LO, MID, HI AC Vehicles (See Climate Control Bulletins, Pages 17-20)

Seat & Steering Wheel: Heated/Cooled Seats & Heated Steering Wheel Settings

Camera: FORD 360 Camera ON or OFF

Temperature Display: Display Outside Temperature (If Available)



# SYSTEM SETTINGS


Factory AMP: Lowers volume power (for Factory Amplifiers)

Reverse Mute: Mute or Lower audio volume when vehicle is in reverse.

Dynamic Guideline: Enable/Disable Reverse Lines  
(Added by our Radio)

Radar Sound: Enable/Disable Reverse Proximity Sensors

RHD: Right Hand Drive vehicle ON/OFF



# SYSTEM SETTINGS


Pre/Next Settings: Steering wheel control seek button orientation

Ambient Light: Enable or Disable Ambient Light Control App (FORD Only)

# EXTRA TIPS



The bottom row of icons have 4 pages. Swipe this bar left or right to access more apps, including the custom apps page, and a climate control menu.



If your Time isn't staying properly, go to the General Settings (Page 1), then Time/Time Zone, and make sure:

- *Automatic Date and Time is **OFF***
- *Automatic Time Zone is **OFF** and Set the Time Zone **Manually***

Factory Configuration update will reset **ALL** settings

Factory Configuration

Check for updates



# FORD TRUCK CLIMATE SETUP

## PRIOR TO INSTALLATION:

IDENTIFY YOUR CLIMATE CONTROL FROM THE OPTIONS BELOW

### MANUAL AC



### AUTO AC



## AFTER INSTALLATION:

SELECT THE PROPER PROGRAM FOR YOUR VEHICLE.



System

Setting Guide >

Car model/Ac >

None	Mando H
Ford	Mando L
General Motors	F150 LO
Toyota	F150 HI
Dodge	Old F150 LO



OK



Save

1. Tap on Settings
2. Tap on System
3. Go to Setting Guide
4. Tap Car model/AC
5. Select your vehicle

Manual Climate systems:

F150 LO

AUTO/DUAL Climate Systems:

F150 HI

6. Tap OK on the bottom of the screen

7. Tap the Back Button/Left Arrow

8. Tap SAVE on the bottom

9. Restart the vehicle and Radio

# GMC/CHEVY TRUCK CLIMATE SETUP

## PRIOR TO INSTALLATION:

IDENTIFY YOUR CLIMATE CONTROL FROM THE OPTIONS BELOW



**MANUAL CLIMATE**



**AUTO CLIMATE**

## AFTER INSTALLATION:

SELECT THE PROPER PROGRAM FOR YOUR VEHICLE.



1. Tap on Settings
2. Tap on System
3. Go to Setting Guide
4. Tap Car model/AC
5. Select Silverado/Sierra

*Manual Climate systems:*

*Car info: Manual a/c*

*AUTO/DUAL Climate Systems:*

*Car info: Auto a/c*

6. Tap OK on the bottom of the screen
7. Tap the Back Button/Left Arrow
8. Tap SAVE on the bottom

9. Restart the vehicle and Radio

# RAM TRUCK CLIMATE SETUP

## PRIOR TO INSTALLATION:

IDENTIFY YOUR CLIMATE CONTROL FROM THE OPTIONS BELOW

**4 FAN SPEED**



**RAM LO**

**7 FAN SPEED**



**RAM MID**

**AUTO AC**



**RAM HI**

**7 FAN SPEED  
W/8" SCREEN**



**RAM HI**

## AFTER INSTALLATION:


SELECT THE PROPER PROGRAM FOR YOUR VEHICLE.



System

Setting Guide >

Car model/Ac >



OK



Save

1. Tap on Settings
2. Tap on System
3. Go to Setting Guide
4. Tap Car model/AC
5. Select your vehicle

**4-Fan Speed:**  
Dodge Ram LO

**7-Fan Speed:**  
Dodge Ram MID

**Auto/Dual OR 8" Screen:**  
Dodge Ram HI

6. Tap OK on the bottom of the screen

7. Tap the Back Button/Left Arrow

8. Tap SAVE on the bottom

9. Restart the vehicle and Radio

# TUNDRA TRUCK CLIMATE SETUP

## PRIOR TO INSTALLATION:

IDENTIFY YOUR CLIMATE CONTROL FROM THE OPTIONS BELOW

### MANUAL AC



### AUTO AC



## AFTER INSTALLATION:

SELECT THE PROPER PROGRAM FOR YOUR VEHICLE.



System

Setting Guide >

Car model/Ac >

Name	Tundra LD
Brand	Tundra HI
General Notes	Tundra HI w/seat heaters
Toyota	



OK



Save

1. Tap on Settings

2. Tap on System

3. Go to Setting Guide

4. Tap Car model/AC

5. Select your vehicle

*Manual Climate systems:*

Tundra LD

*AUTO/DUAL Climate Systems:*

Tundra HI

*With Seat Heaters:*

Tundra HI w/seat heaters

6. Tap OK on the bottom of the screen

7. Tap the Back Button/Left Arrow

8. Tap SAVE on the bottom

9. Restart the vehicle and Radio

# FOR MORE INFORMATION & TECH SUPPORT

All manuals and setup guides can be found on our website:

[Linkswellinc.com](https://linkswellinc.com)

Find us on 

Our Facebook groups and YouTube channel can also provide tech support.

[YouTube Link](#)

Watch us on



We can be reached by our office number: (909) 375-0633

Mon-Thurs: 7am-4pm PST

Fri: 7am-3pm PST

For a more in-depth settings guide: [Linkswellinc.com](https://linkswellinc.com)



**LINKSWELL**  
TECHNOLOGY TOGETHER