


ITEM NAME / NOM D'ITEM: SHORELINE ACCENT CHAIR

ITEM # / NO.ITEM: 704042


## PARTS LIST / LISTE DES PIÈCES

(1)



×1


(2)




×1

## ASSEMBLY INSTRUCTIONS / INSTRUCTIONS D'ASSEMBLAGE

I



II



Please use the attached adjustable footglides to level the chair on uneven surface.