

E-Commerce by Enitial Lab

ASSEMBLY INSTRUCTIONS

MODEL#

CM3789-BT

Questions?


GIVE US CALL: 1-888-980-5122 MON-FRI 8:30AM - 5:30PM (PST)

TOOLS REQUIRED



Allen Wrench

(Included)





2 - People Recommended

ASSEMBLY RATING



EASY → DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.

VERSION # 20-08-31





Thank you for your purchase!

We hope you enjoy this new addition to your home for many years to come.

Our commitment to providing quality products does not simply end when you purchase our product. We fully stand behind our products from start to finish. Our customer service department is available Monday – Friday 8:30 AM – 5:30 PM Pacific and can help with assembly questions as well as, if necessary, replacing damaged or missing parts. To help expedite our service, please have these assembly instructions readily available, along with your order receipt.



Consumer Hotline Toll-Free 1-888-980-5122



WEBSITE www.foagroup.com











Monday to Friday 8:30AM- 5:30PM (PST)



E-MAIL cs.ec@foagroup.com



FurnitureOfAmerica



Are you missing anything?	Check out our Quick Tips!
Double-check all parts, hardware and accessories listed on Page 6 are accounted for.	We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!
Should we send any replacements?	Prep Time!
 Are there any irregularities or flaws in the parts? We can send replacements!	Please review the assembly instructions and all diagrams prior to assembling. Arrange parts as recommended on Page 7 and group identical hardware together to make assembling easier.

PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.





Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.





Suitable Location

Assembling near the area of the intended location is highly recommended.





Sufficient Space

Make sure you have enough space to move around during the assembly.





Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent scratches.





Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

ASSEMBLY AND CARE ADVICE



FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Position each part correctly and insert screws or bolts into their respective holes.



Use the appropriate hand tools or power tools for assembly. Select steps, such as tightening screws and/or bolts, may require hand tools to avoid causing damage during assembly.



Turn clockwise to tighten and only tighten when step is completed or when instructed to do so.



Save the instructions and store any supplied tools for later maintenance.



After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.


IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

BAR TABLE

CM3789-BT



- Please keep instructions for future reference.
- · Check the quantity and irregularity of parts and hardware before you start.



PARTS



1pc



Front Panel





Cup Hanger





Middle Shelf



L Shape Leg

(#2) 1pc

Back Frame






Small Frame





Bottom Shelf



(#3) 2pcs



Side Panel





Wine Rack





Out Frame





RF Wireless





Top





Connect Tube




Support Leg

BAR TABLE

CM3789-BT



- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.



HARDWARE



42pcs

Bolt 1/4" x 5/8"



4pcs



Bolt 1/4" x 2"

#C 1pc





Bolt 1/4" x 2-3/16"

#D 1pc



Allen Wrench M4






< #3ັ

#A


Align side panels (#3) and small frame (#6) to the front and back frame (#1,2). Secure by using bolts (#A).

3

Part #4 x 1pc Hardware #B x 4pcs Hardware #D x 1pc



Align top (#4) to the frame, then secure by using bolts (#B).



1) Align support legs (#12) and center leg (#13) to the out frame (#11), then secure by using bolts (#A).

4

Part #11 x 1pc


Part #12 x 4pcs

Part #13 x 1pc


Hardware #A x 12pcs


Hardware #C x 1pc


Hardware #D x 1pc




3) Secure center leg (#13) to the front frame (#1) by using bolts (#C).









2) Align out frame (#11) to back frame (#2), then secure by using bolts (#A).






Connect the adaptor (#14) to the plug on the top (#4).



8



ASSEMBLY COMPLETED



Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.

✓ Keep this handy!

Please retain this instruction manual and any order-related information for future reference.

✓ Lift, don't drag!

To avoid damage to product please always LIFT the product when transporting of adjusting the placement.