

# ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

182992 Side Chair

### ITEM: 182992

#### **ASSEMBLY INSTRUCTIONS**

#### **ASSEMBLY TIPS:**

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



#### **WARNING!**

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

10 MINUTES

### PARTS IDENTIFICATION

B SEAT CUSHION WITH FRAME 1PC

C FRONT LEG 2PCS

D SIDE STRETCHER 2PCS

#### HARDWARE IDENTIFICATION

1	LONG BOLT WITH WASHER (M6 x 80mm - BLK)		4PCS
2	MEDIUM BOLT WITH WASHER (M6 x 60mm - BLK)		4PCS
3	SHORT BOLT WITH WASHER (M6 x 40mm - BLK)		3PCS
4	PAN HEAD SCREW (M5 x 38mm)	(s) <u> </u>	4PCS
5	ALLEN WRENCH (M4 x 55mm- GD)		1PC

#### NOTE:


Quantities shown are for one chair.

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.


## ITEM: 182992 ASSEMBLY INSTRUCTIONS




STEP 1



## STEP 2



## STEP 3 COMPLETE






PAGE 3 OF 3

COASTERFURNITURE.COM

ITEM: **182992** 





Note: Dimension tolerance ±5%