

The power to make. The power to move. Create anywhere using the KitchenAid Go™ Cordless Food Chopper. Powered by a rechargeable 12v MAX removable battery, the new cordless food chopper delivers 25 minutes of continuous run time* and performance, so you can cook wherever, whatever, and however you choose. *Maximum initial battery voltage (measured without a workload) is 12 volts. Nominal voltage is 10.8. Actual run time will vary based on recipe and/or attachments used. Battery life impacted by factors such as battery age and use.

- Top Features
- Cordless
- Power, Without The Cord
- Setup is Simple

KitchenAid Go™ Cordless Food Chopper - battery included

KFCR531BM

Available Finishes/Colours

-  KFCR531BM
Black Matte

Dimensions		Features	
Depth	5.71	Capacity	5 Cup
Height	10.45	Handle	Yes
Width	7.24	Number Of Speeds	2
		Pour Spout	Yes
Specifications			
Country Of Origin	China		
Optional Accessories	KRB12		
Electrical			
Hz	50/60		
Plug Type	2 Prong Plug		
Accessories Included			
Work Bowl Cups	5.0		
Accessories			
Included Accessories	In Bowl Storage; Mulitpurpose Blade; Storage Tray		
Features			
Base Material	Plastic		