





Unpack and check contents:

registration.

- (1) Deluxe ceiling mount assembly
- (1) Custom mounting bracket
- (4) 5/16" flange nuts

- (8) M12 Flat washers
- (8) M12 X 20mm hex bolts

INSTALLATION INSTRUCTIONS

- 1. Turn your projector upside down.
- 2. Place the custom mounting bracket on the projector so the small triangle in the bracket is toward the front of the projector and all eight holes in the custom bracket align with the eight mounting inserts in the bottom of your projector.
- 3. Place (1) M12 flat washer on each of the (8) M12 X 20mm bolts, starting them all by hand and secure them using the proper size wrench. Using the proper wrench, securely tighten all eight mounting bolts at this time.

WARNING: IMPROPER INSTALLATION MAY RESULT IN SERIOUS PERSONAL **INJURY!** All components must be securely fastened to each other and to the ceiling, **AND** the ceiling **MUST** be capable of supporting 5 times the total weight of the installation. If it cannot, the ceiling **MUST** be reinforced.

- 4. Be sure the method of support you are using for the VCM ceiling mount is securely installed to the ceiling. If not, the ceiling must be reinforced. Improper installation may result in serious personal injury.
- Attach the VCM housing to your method of support and tighten firmly so the VCM housing is square to the 5. screen.

WARNING: Installing a ceiling mount requires the presence of two persons familiar with mechanical installations. A third assistant is recommended

With the help of your one or two assistants, lift the projector and install it on the studs extending from the 6. mounting plate. Make sure the custom mounting plate is seated in the slots and Tighten securely using the four 5/16" flange nuts.

For projector alignment see attached sheet.

8803-000063 02/05