




ASSEMBLY INSTRUCTIONS

D1903-20







MAISIE SIDE CHAIR


Thank you for purchasing this quality product. Be sure to check all packing materials carefully for small parts, which may have come loose inside the carton during shipment. Identify and count all items and compare with the parts list and/or hardware list shown below.

PARTS LIST

NO	DESCRIPTION	SKETCH	QTY
1	CHAIR BACK REST		2 PCS
2	CHAIR SEAT		2 PCS
3	LEG		4 PCS

HARDWARE LIST

NO	DESCRIPTION	SKETCH	QTY
A	JCBC BOLT - M6 x 80mm		8 PCS
B	JCBC BOLT - M6 x 60mm		8 PCS
C	JCBC BOLT - M6 x 40mm		4 PCS
D	SPRING WASHER - M6		20 PCS
E	FLAT WASHER - M6		20 PCS
F	ALLEN KEY - M4		1 PC



IMPORTANT NOTE :


* Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched.

ASSEMBLY INSTRUCTIONS


D1903-20

MAISIE SIDE CHAIR



Step 1.



Step 2.



Step 3.



COMPLETE ASSEMBLY