



3900-SECTPH (57H, 19, 23, 59H, 58H) in leather 824-02

FLEXSTEEL®

© Flexsteel Industries, Inc. | Last Updated 08/23

19 57H 58H 59H	23	FEATURES
●	●	Flexsteel Spring Unit
	●	DualFlex
		Sinuous Wire
●	●	Back Construction
	●	Attached
●	●	Seat Construction
	●	Attached
●	●	Seat Cushion(s)
	●	High-Density (HC)

- Standard
- Optional

PRODUCT DIMENSIONS	OVERALL			SEAT			Arm Height	Open Depth	Wall Clearance
	Height	Width	Depth	Height	Width	Depth			
Armless Chair -19	40"	26"	39"	19"	26"	21"			
Full Wedge -23	40"	64"	41"	19"	38"	23"			
LAF Power Recliner with Power Headrest -57H	40"	30"	39"	19"	25"	21"	24"	67"	5"
RAF Power Recliner with Power Headrest -58H	40"	30"	39"	19"	25"	21"	24"	67"	5"
Armless Power Recliner with Power Headrest -59H	40"	26"	39"	19"	26"	21"		67"	5"
Straight Console -72	40"	9"	38"	24"	9"	23"			

NOTES

A clean, transitional design

Padded, soft sloped track arms

Choose from six modular components to build a sectional that fits your space

The straight console contains two cupholders for drinks

Adjust from an upright to a fully reclined position with the touch of a button

Charge electronic devices with the dual USB-A port located in the power button

Sustainably sourced wood frame delivers exceptional durability

Contoured, high-density foam seat cushions provide lasting, everyday comfort and support

Upholstered in your choice of more than 50 durable leathers

Handcrafted in North America

The power control allows you to independently adjust the recline and headrest.


A separate home button returns the headrest and footrest to their original positions with one touch.

A USB port is included on the power control for powering electronics.

Zero draw technology only uses power when the USB port is in use.



Power Recline
& Headrest



Interlocking Brackets







Interlocking brackets securely attach one sectional component to another to prevent them from separating even when reclining.

3900 Catalina | Components & Configurations




Sectionals

Components

LAF = Left-Arm-Facing
RAF = Right-Arm-Facing



Sample Configurations



Scale 1/4"=1'

Dimensions are in inches and are subject to variance.
© Flexsteel Industries, Inc. 7/22
FLX-CP-FR-CC-3900

FLEXSTEEL®