

# M131-421-262LA MODA DISPLAY UNIT PIER

## MODERN LA MODA

### ASSEMBLY INSTRUCTIONS

**PLEASE UNPACK ALL PARTS AND CHECK QUANTITY AGAINST PARTS LIST BEFORE DISCARDING PACKING CARTON!**


- 1) Unpack the Display Unit Pier **M131-421-262** and place the Glass shelf (10) to the corresponding position with adjustable shelf pin (9), tighten by Philips screw driver as shown in Diagram A.
- 2) Place Display Unit Pier to each side of completed assembly , using Flat Washer (B), Lock Washer (C) and Bolt (D). Double check and make sure they are even and align, then tighten the entire bolts with Wrench provided (E) as shown in Diagram B.
- 3) Make sure the 2 Display Unit Piers on each side are even and align then screws to secure the Unit Piers together as shown in Diagram C.

\*\*\* NOTE KEEP THIS SHEET \*\*\*

In the unlikely event that you would need a replacement part for your furniture, please contact your local authorized Caracole International dealer. If you need replacement hardware quickly, it could be purchased from your local hardware store.

M131-421-262				
LA MODA DISPLAY UNIT PIER				
Part List				
Hardware List		Part Number	QTY	
9		Adjustable Shelf Pins With Hole	M131-421-262-0319	8
10		Glass Shelf	M131-421-262-028	2
11		Magnetic Catch	M131-421-262-012	2
12		Hinge	M131-421-262-005	4
13		Leaf Support	M131-421-262-030	4
14		Handle	M131-421-262-0309	2
15		Adjustable Shelf	M131-421-262-023	1
16		Adjustable Floor Glide	M131-421-262-075	4
17		Tipping Restraint	M131-421-262-0157	1
18		Bridge Plate	M131-421-263-0339	1

RTA Hardware			
Hardware List			QTY
A		Screw (M131-421-261)	4
B		Flat Washer (M131-421-263)	3
C		Lock Washer (M131-421-263)	3
D		Bolt (M131-421-263)	3
E		Wrench (M131-421-263)	1



**M131-421- 262  
Display Unit Pier**

