






Product Assembly Instructions

CHANNELL BENCH


PART LIST

 A : BACKREST x1	 B : CUSHION SEAT x1	 C : SIDE LEG (L & R) x2
 D : SUPPORT x1		


HARDWARE LIST

 E : JCBC SCREW M6 x 45mm x7	 F : JCBC SCREW M6 x 70mm x4	 G : SPRING WASHER 1/4" x11
 H : M4 ALLEN KEY (BALL SHAPE) LONG x1		


STEP 1




STEP 2



STEP 3



STEP 4







Product Assembly Instructions

CHANNELL DINING CHAIR


PART LIST




A : BACKREST x1



B : BACK LEG x1



C : SEAT CUSHION x1



D : FRONT LEG (L &R) x2

HARDWARE LIST



E : JCBC SCREW M6 x 45mm x12



F : SPRING WASHER 1/4" x12





G : FLAT WASHER 1/4" x8




H : M4 ALLEN KEY (BALL SHAPE) LONG x1


STEP 1




STEP 2



STEP 3



STEP 4







Product Assembly Instructions

CHANNELL DINING TABLE


PART LIST

 A : TABLE TOP x1	 B : TABLE LEG (L) x2	 C : TABLE LEG (R) x2
 D : TABLE LEG STRETCHER x2	 E : TABLE LEG SUPPORT RAIL x2	


HARDWARE LIST

 F : JCBC SCREW M6 x 50mm x8	 G : JCBC SCREW M6 x 25mm x4	 H : SPRING WASHER 1/4" x12
 I : FLAT WASHER 1/4" x8	 J : PAN HEAD SCREW M5 x 32MM x4	 K : ALLEN KEY M4 x1


STEP 1



STEP 2



STEP 3



STEP 4

