

Assembly Instructions



ITEM NO. D1010-25
MARLEY DINING BENCH

Thank you for purchasing this quality product. Be sure to check all packing materials carefully for small parts, which may have come loose inside the carton during shipment. Identify and count all items and compare with the PARTS LIST and/or HARDWARE LIST shown below.





Caution: Please read the instructions thoroughly before assembly.

1. We recommend that you assemble this product with the assistance of another person; this will make the assembly easier, and will help eliminate damage to the product or injury to persons during assembly.
2. Please do not over tighten screws or bolts until the assembly is completed.
3. Please put all parts on a non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.


PARTS LIST:

NO.	COMPONENT	SKETCH	QTY.
A	BENCH TOP		1 pc
B	BENCH LEGS		4 pcs

HARDWARE LIST:

NO.	COMPONENT	SKETCH	DESCRIPTION	QTY.
1	HEX NUT		φ5/16"	8 pcs
2	LOCK WASHER		φ5/16"	8 pcs
3	FLAT WASHER		φ5/16" x 19mm	8 pcs
4	OPEN WRENCH		12mm	1 pc

STEP 1



STEP 2

