


ASSEMBLY INSTRUCTION

Model : D8112DT

Description : Dining Table


Thank you for purchasing this quality product. Be sure to check all packing materials carefully for small parts that may have come loose inside the carton during shipment

PART LIST : TABLE				HARDWARE LIST				
No	Description	Diagram	Quantity	PACKED IN INSIDE TABLE				
				No	Description	Diagram	Size	Quantity
A	Table		1pc	1	JCBB Bolt		M8 x 60mm	8pcs
				2	Spring Washer		5/16"	8pcs
B	Leg		4pcs	3	Flat Washer		5/16"IDx22mm OD	8pcs
				4	Allen Key		M5 x 65mm	1pc




COMPLETE ASSEMBLY

STEP 1 : Attach Table Dining Top (A) at soft surface



STEP 2 : Attach Leg Post (B) at Table Top (A) With Flat Washer (3), Spring Washer (2) and JCBB Bolt (1) and Tighten with Allen Key (4)






ASSEMBLY INSTRUCTION

Model : D8112DC

Description : Dining Chair


Thank you for purchasing this quality product. Be sure to check all packing materials carefully for small parts. that may have come loose inside the carton during shipment

PART LIST : CHAIR				HARDWARE LIST				
No	Description	Diagram	Quantity	PACKED IN INSIDE CHAIR				
				No	Description	Diagram	Size	Quantity
A	Back Rest		1pc	1	JCBB Bolt		M8 x 80mm	4pcs
				2	JCBB Bolt		M8 x 60mm	4pcs
B	Front Leg		2pcs	3	Spring Washer		5/16"	8pcs
				4	Flat Washer		5/16"IDx22mm OD	8pcs
C	Cushion Seat		1pc	5	Allen Key		M5 x 65mm	1pc



COMPLETE ASSEMBLY

STEP 1 : Align the cushion seat (C) to the Back Rest (A) by secure with JCBB Bolt (1) ,Spring Washer (3) , flat washer (4) and tighten them with Allen Key (5) (DO NOT TIGHTEN BOLTS DURING THIS STEPS)



STEP 2 : Align Front Leg (B) into cushion seat (C) and fix with JCBB Bolt (2), Spring Washer (3), Flat Washer (4) tighten them with Allen Key (5) as shown.

