ASSEMBLY INSTRUCTIONS

ITEM NO: D530-61
Wooden Dining Chair

Α

Thank you for purchasing this quality product. Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched. Be sure to check all packing materials carefully for small parts may have come loose inside the carton during shipment, clarify and count all parts and compare with the parts list below. Do not tighten all screws / bolts until all completely assembled.

PART LIST			
NO.	COMPONENT	QTY.	
А	Chair Back	1 pc	
В	Chair Seat With Box Frame	1 pc	
С	Left Front Leg -	1 pc	
D	Right Front Leg -	1 pc	
Е	Left Stretcher -	1 pc	
F	Right Stretcher -	1 pc	


HARDWARE LIST				
NO.	COMPONENT		QTY.	
1	JCBC Screw M6 x 35MM		2 pcs	
2	JCBC Screw M6 x 60MM		4 pcs	
3	JCBC Screw M6 x 80MM		4 pcs	
4	Spring Washer 1/4"		10 pcs	
5	Flat Washer 1/4"		10 pcs	
6	Pan Head Screw #8 x 32MM	«Jununu»	4 pcs	
7	Allen Key		1 pc	

NOTE: YOU WILL ALSO NEED A SCREWDRIVER (NOT PROVIDED)

These parts are cumbersome and heavy. Therefore, two people are recommended in order to prevent personal injury and insure the parts are not damaged during the assembly.

Important Notes

- * Keep all hardware parts out of reach of chidren!
- * Tighten screws periodically! With the use of this product bolts and screws may become loose over time
- * Don't attempt to modify parts!



Cleaning instruction: Clean using soft cloth

Made In Malaysia

ASSEMBLY INSTRUCTIONS

ITEM NO: D530-61 **Wooden Dining Chair**

