

ASSEMBLY INSTRUCTIONS.

KENT OUTDOOR DINING CHAIR TAUPE-SET OF TWO

QX-1017-39



THANK YOU FOR YOUR PURCHASE!

PARTS AND HARDWARE.

PARTS LIST

No.	DESCRIPTION	IMAGE	QTY
P1	SEAT	$\left(\right)$	1
P2	BACK	\bigcirc	1
P3	LEG1		1
P4	LEG2		1

HARDWARE LIST

No.	DESCRIPTION	IMAGE	QTY
Н1	BOLT(6X40MM)	and a second	5
H2	SPRING WASHER (6X10X1MM)	Ø	4
Н3	FLAT WASHER (6X12X1 MM)		5
H4	ALLEN KEY(M5)	2	1
H5	BOLT(6X16MM)		4
H6	ALLEN KEY(M4)	2	1

NOTES.

Thank you for purchasing this quality product! Be sure to check all packing material carefully for small part that may have come loose inside the carton during shipping

CAUTION: Ensure not to overtighten screws to reduce the risk of stripping or breakage.

