

UTTERMOST

ASSEMBLY INSTRUCTIONS

21418

WARNING: TO AVOID RISK OF ELECTRICAL SHOCK, BE SURE TO SHUT OFF WHILE POWER BEFORE INSTALLING OR SERVICING THIS FIXTURE.

We suggest a licensed professional electrician for installation

Installation Steps

1. Turn power off at fuse or circuit box before starting installation process.
2. Carefully unpack your new fixture and lay out all the parts on a clear surface.
3. Choose desired hanging wire length for the light fixture. Assemble the Stems to the desired length. Attach the Stem assembly to the Fixture body. Hand-tighten until snug. Place the Canopy lock ring and the Canopy over the Stem. IF NEEDED THREAD THE SWIVEL TO THE UPPERMOST STEM. Hand-tighten until snug.
4. Thread the Ground screw into the hole of the Crossbar. Secure the Crossbar assembly to the outlet box with the Outlet box screws.
5. Make Wire connections with Wire Connector:
 - The Black Wire from fixture to Black Wire from power source.
 - The White Wire from Fixture to White Wire from power source.
 - Attach the Ground Wire and house ground wire to the Crossbar with the green Ground screw.
6. Carefully tuck wires back into the Outlet Box.
7. Attach the Canopy over the Swivel. Secure with canopy lock ring.
8. Secure the Shades to the Fixture body with the Mounting screws as shown. Tighten until snug.
9. Install the light bulbs (Not Supplied) in accordance with the fixture's specifications. **DO NOT EXCEED THE MAXIMUM WATTAGE RATING!**

