



*ASSEMBLY INSTRUCTIONS*  
*COASTER FINE FURNITURE*



*Fine Furniture for every stage of life*

**109371**  
***DINING TABLE***

REVISION 0 : 08/16/2024

PAGE 1 OF 6

COASTERFURNITURE.COM

ITEM:109371



# ASSEMBLY INSTRUCTIONS


## ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



## WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME 35 MINUTES

## PARTS IDENTIFICATION


B2: BASE

A LEG A




2PCS

B LEG B



2PCS


C TOP FRAME



1PC

B1: TOP

D TOP



1PC

Z


## HARDWARE IDENTIFICATION

1 SHORT BOLT  
(1/4" x 15mm BLK)



4PCS

2 LONG BOLT  
(1/4" x 56mm BLK)



4PCS

3 SUCTION CUP



6PCS

4 LEVELER  
(1/4" x 12mm BLK)



4PCS

5 ALLEN WRENCH  
(4mm)



1PC

Hardware pack is located in 109371B2

PAGE 2 OF 6

COASTERFURNITURE.COM


ITEM:109371




# ASSEMBLY INSTRUCTIONS

## STEP 1

Do not tighten until each step is completed or instructed.




## STEP 2




ITEM:109371

# ASSEMBLY INSTRUCTIONS

## STEP 3



## STEP 4




ITEM:109371





# ASSEMBLY INSTRUCTIONS

## STEP 5



## STEP 6 COMPLETE




# ITEM:109371

## ASSEMBLY INSTRUCTIONS



**Product Size : 1797 X 895 X 775 H (MM)**

**Product Size : 70.75" X 35.25" X 30.5"**



Note : Dimension tolerance  $\pm 5\%$