



*ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE*



Fine Furniture for every stage of life

**909478
ACCENT CHAIR**

REVISION 0: 07/08/2021

COASTERFURNITURE.COM

PAGE 1 OF 4

ITEM: 909478

ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!


1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME 10 MINUTES

PARTS IDENTIFICATION


A



BASE

1PC


B



BACK CUSHION

1PC

C



LEG


4PCS

ITEM: 909478


ASSEMBLY INSTRUCTIONS




STEP 1





STEP 2




STEP 3



STEP 4



ITEM: 909478



Note : Dimension tolerance $\pm 5\%$

COASTERFURNITURE.COM