


aspenhome

Distributed by Furniture Values International, LLC



ITEM NO: I35-303 66" Executive Desk w/Power

HARDWARE PACK			COMPONENTS LIST	
В	Bolt (Ø1/4"*2-1/2") Lock Washer (Ø1/4") Flat Washer (Ø1/4"*3/4")	16 Pcs 16 Pcs 16 Pcs		8 Pcs
	Allen Wrench (4mm)	1 Pc		



- 1. Put the desk upside down on a soft, clean surface.
- 2. Attach legs to the bottom of desk using bolts A,lock washer B and flat washer C.See detail 1.
- 3. Turn the desk to the upright position.