

ASSEMBLY INSTRUCTION


Model : ASHLEY-BROWN-FB-HB LAMP & SPEAKER


Description : FULL BED HEADBOARD
LAMP & SPEAKER

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts that may have come loose inside the carton during shipment.

PART LIST :

HARDWARE LIST :

| No. | Description | Diagram | Quantity | No. | Description | Diagram | Size | Quantity |
|-----|---------------------|---|----------|-----|---------------|---|-----------|----------|
| A | HEADBOARD |  | 1 | D | JCBB SCREW |  | M8 x 40mm | 6 |
| B | LEFT HEADBOARD LEG |  | 1 | E | SPRING WASHER |  | M8 x 15mm | 6 |
| C | RIGHT HEADBOARD LEG |  | 1 | F | FLAT WASHER |  | M8 x 22mm | 6 |
| | | | | G | ALLEN KEY |  | M5 | 1 |
| | | | | H | ADAPTOR |  | | 1 |



ASSEMBLY INSTRUCTION

Description : FULL BED-HEADBOARD LAMP & SPEAKER
 -FOOTBOARD & SLATS
 -SIDERAILS

Model : ASHLEY-BROWN-FB-HB LAMP SPEAKER-FB-FB-SR

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts that may have come loose inside the carton during shipment.



PART LIST :

HARDWARE LIST :

| No. | Description | Diagram | Quantity | No. | Description | Diagram | Size | Quantity |
|-----|--------------------------|---------|----------|-----|------------------|---------|-----------|----------|
| A | HEADBOARD LAMP & SPEAKER | | 1 | F | JCBB SCREW | | M8 x 25mm | 8 |
| B | FOOTBOARD | | 1 | G | SPRING WASHER | | M8 x 15mm | 8 |
| C | SIDE RAIL | | 2 | H | FLAT WASHER | | M8 x 22mm | 8 |
| D | WOODEN SLAT | | 3 | I | ALLEN KEY | | M5 | 1 |
| E | WOODEN SUPPORT | | 3 | J | CB SCREW | | M4 x 32mm | 6 |
| | | | | K | SCREW DRIVER (*) | | | 1 |

Lamp Touch Sensor :
 i) Switch on
 ii) Lighter
 iii) More lighter
 iv) Switch off

(*) The manufacturer does not provide item K.




Step 1

Step 2

Push the side rail (C) to meet with wooden slat (D) and fix the CB Screw (J) by using the Screw Driver (K).

Step 4



Step 3

Step 5

Step 6

WALL
Adaptor for speaker

WALL
Adaptor for lamp