

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

722873 *TV STAND*

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.

2. Please check to see that all hardware and parts are present prior to start of assembly.

3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately. 2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME



MAX TV SIZE: 75"

PARTS IDENTIFICATION



NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.



HARDWARE IDENTIFICATION

Z	_						
NO	DESCRIPTION	FIGURE	Q'TY	NO	DESCRIPTION	FIGURE	Q'TY
1	GLUE 40g		1 PC	11	BOLT Ø4x28mm SR		4 PCS
2	WOODEN DOWEL Ø8 x 30mm		24 PCS	12	RAIL SCREW Ø 3x15mm BLK		7 PCS
3	CAM BOLT Ø7 x 35.5mm SR		13 PCS	13	PLASTIC COVER Ø 52mm		2 PCS
4	CAM LOCK Ø15 x 12mm SR		13 PCS	14	LEG 47mm BLK	·	4 PCS
5	SCREW Ø 4.5x42mm SR	AUGUSTUS DE LA CONTROL DE LA C	9 PCS	15	SUPORT LEG Ø45mm BLK		2 PCS
6	PIN FOR ADJUSTABLE SHELF Ø4.9x8mm SR		8 PCS	16	SCREW Ø4x19mm BLK		8 PCS
7	DOOR CATCH		2 PCS	17	SQUARE FLOOR PROTECTOR 50x50mm		4 PCS
8	HINGE Ø35mm SR		4 PCS	18	ROUND FLOOR PROTECTOR Ø50mm		2 PCS
9	HINGE SCREW Ø4x15mm SR		16 PCS	19	STICKER Ø20mm		3 PCS
10	HANDLE L = 120mm		2 PCS				

Z8, Z10, Z11, Z13, Z14, Z15 not included in blister packaging.


NOTE:


Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.






















































































STEP 14






PAGE 10 OF 13

COASTERFURNITURE.COM









HORIZONTAL BY SCREW AADJUSTMENT





LATERAL BY SCREW B ADJUSTMENT



VERTICAL BY SCREW C ADJUSTMENT








STEP 17

COMPLETE














Note: Dimension tolerance ±5%