

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

111101 DINING TABLE



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME



PARTS IDENTIFICATION

<u>B1 (BOX 1)</u>

B3 (BOX 3)

TOP MARBLE



1PC

D LEG FRAME



2PCS

B2 (BOX 2)

B TOP FRAME



1PC

C BASE



1PC

NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.

HARDWARE IDENTIFICATION

Z-HARDWARE PACK IS LOCATED IN 111101 (B3)

1	ALLEN WRENCH	-	1PC
2	SHORT BOLT (M8*50) mm	0	20PCS
3	FLAT WASHER D20*2	0	20PCS
4	FRAME REST		8PCS

Hardware pack is located in 111101 B3

NOTE:


Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

PAGE 3 OF 5

COASTERFURNITURE.COM

ASSEMBLY INSTRUCTIONS


STEP 1






STEP 2






STEP 3 A:TOP MARBLE



STEP 4




THE BOTTOM FIXED ADJUST FEETS

PAGE 4 OF 5



COASTERFURNITURE.COM





Note : Dimension tolerance \pm 5%