


## ASSEMBLY INSTRUCTIONS

MODEL # FM7417AK-Q

#### Questions?

GIVE US A CALL: 1-888-980-5122 MON-FRI 8:30AM - 5:30PM (PT)

#### TOOLS REQUIRED



Screwdriver (Not included)



Allen Wrench



2 - People





The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.






Thank you for your purchase!

We hope you enjoy this new addition to your home for many years to come.

Our commitment to providing quality products does not simply end when you purchase our product. We fully stand behind our products from start to finish. Our customer service department is available Monday – Friday 8:30 AM – 5:30 PM Pacific Time and can help with assembly questions as well as, if necessary, replacing damaged or missing parts. To help expedite our service, please have these assembly instructions readily available, along with your order receipt.



# PRE ASSEMBLY

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.


















#### Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.

#### Suitable Location

Assembling near the area of the intended location is highly recommended.

#### **Sufficient Space**

Make sure you have enough space to move around during the assembly.

#### **Avoid Scratches**

Use cardboard, blankets or a carpeted area while assembling furniture to prevent to prevent scratches and damages.


#### **Flat Surface**

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

## ASSEMBLY AND CARE ADVICE



FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.




Use the appropriate hand tools or power tools for assembly. Select steps, such as tightening screws and/or bolts, may require hand tools to avoid causing damage during assembly.



Turn clockwise to tighten and only tighten when step is completed or when instructed to do so.




Save the instructions and store any supplied tools for later maintenance. for assembly. uch as tightening bolts, may require void causing assembly.




IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.




- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.






## EXPLODED VIEW




## FM7417AK-Q is packed in 3 cases

Carton	Disignation	Part		Hardware
	Headboard	1		A 12pcs B 12pcs
FM7417AK-Q-HB	H/Board Leg (R/ L)	2		C 12pcs
	HB Support Rail	3		
FM7417AK-Q-FB	Footboard	4		
	Footboard Legs	5		
FM7417AK-Q-R	Side Rail	6		E 8pcs F 8pcs
	Slat	7		G 8pcs
	Support Leg	8		⊛ <del></del> I6pcs

### **ASSEMBLY INSTRUCTIONS**



### **ASSEMBLY INSTRUCTIONS**



### **ASSEMBLY INSTRUCTIONS**

