



Power Rocking Recliner with Power Headrest
4504-51H in 323-70



Power Rocking Recliner with Power Headrest
4504-51H in 323-70



Power Rocking Recliner with Power Headrest
4504-51H in 323-70

FLEXSTEEL®

© Flexsteel Industries, Inc. | Last Updated 02/24/2022

53	FEATURES	
51M		
51H		
51		
50M		
50H		
50		
	Flexsteel Spring Unit	
●	DualFlex	
	Back Construction	
●	Attached	
	Seat Construction	
●	Attached	
	Seat Cushion(s)	
●	High-Density (HC)	
	Tailoring	
○	Arm Covers	

- Standard
- Optional

PRODUCT DIMENSIONS	OVERALL			SEAT			Arm Height	Open Depth	Wall Clearance
	Height	Width	Depth	Height	Width	Depth			
Swivel Gliding Recliner -53	42"	39"	41"	20"	21"	21"	25"	68"	14"
Power Rocking Recliner -51M	42"	39"	41"	20"	21"	21"	25"	68"	14"
Power Rocking Recliner with Power Headrest -51H	42"	39"	41"	20"	21"	21"	25"	68"	14"
Rocking Recliner -51	42"	39"	41"	20"	21"	21"	25"	68"	14"
Power Recliner -50M	42"	39"	41"	20"	21"	21"	25"	68"	5"
Power Recliner with Power Headrest -50H	42"	39"	41"	20"	21"	21"	25"	68"	5"
Recliner -50	42"	39"	41"	20"	21"	21"	25"	68"	5"

NOTES

Available in more than 250 fabric options
Also available in Performance fabrics - Revolution and LiveSmart
Power mechanism allows you to smoothly recline to any position.
Power headrest mechanism allows you to adjust the headrest.
Two power buttons allow you to operate the reclining and headrest mechanisms independently.
Single USB port is included on the power button control.
Safety locks prevent the recliner from rocking while reclining.
Removable back allows for easy lifting and maneuvering through doorways.
Swivels a full 360 degrees.
Glides or reclines from any swivel position.
Swivels in all directions while reclined.
Safety locks prevent the furniture from gliding while reclining.
Removable backs allow for easy lifting and maneuvering through doorways.
Safety locks prevent the furniture from rocking while reclining.
The power control allows you to independently adjust the recline and headrest.
A separate home button returns the headrest and footrest to their original positions with one touch.
A USB port is included on the power control for powering electronics.
Zero draw technology only uses power when the USB port is in use.
Lower the footrest by applying pressure to it in a downward motion. Lowering the footrest with the handle can damage the recliner.
Power allows you to smoothly recline to any position.
A single USB port is included on each power button control on styles with arms.

