

ASSEMBLY INSTRUCTIONS

MODEL # CM-OT1845-3PK


Questions?

GIVE US A CALL: 1-888-980-5122 MON – FRI 8:30AM – 5:30PM (PT)

TOOLS REQUIRED



Allen Wrench








Thank you for your purchase!

We hope you enjoy this new addition to your home for many years to come.

Our commitment to providing quality products does not simply end when you purchase our product. We fully stand behind our products from start to finish. Our customer service department is available Monday – Friday 8:30 AM – 5:30 PM Pacific Time and can help with assembly questions as well as, if necessary, replacing damaged or missing parts. To help expedite our service, please have these assembly instructions readily available, along with your order receipt.



PRE ASSEMBLY

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.


















Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.

Suitable Location

Assembling near the area of the intended location is highly recommended.

Sufficient Space

Make sure you have enough space to move around during the assembly.

Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent to prevent scratches and damages.


Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

ASSEMBLY AND CARE ADVICE



FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.







Turn clockwise to tighten and only tighten when step is completed or when instructed to do so.

Use the appropriate hand tools or power tools for assembly. Select steps, such as tightening screws and/or bolts, may require hand tools to avoid causing damage during assembly.



Save the instructions and store any supplied tools for later maintenance.


After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

TABLE SET CM-OT1845-3PK





- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.



	PARTS		
#1) 2pcs	#2)2pcs	#3)2pcs	#4)2pcs
Chair Back	Chair Seat	Left Arm	Right Arm
#5 1pc	#6) 4pcs	#7)2pcs	#82pcs
Table Top	Table Leg	Seat Cushion	Back Cushion
	HARDWAR	RE	
(#A) 8pcs	#B 16pcs	#C 4pcs	#D 32pcs
		00	Ø
Bolt M6 x 45mm	Bolt M6 x 38mm	Gasket	Flat Washer
₩E) 1pc	₩F) 16pcs		
Allen Wrench	Bolt M6 x 20mm		

ASSEMBLY INSTRUCTIONS







Part #8 x 1pc

x 2

ASSEMBLY INSTRUCTIONS

Align legs (#6) to the top (#5), then secure by using bolts (#F) with washers (#D).





ASSEMBLY INSTRUCTIONS

