Assembly Instruction for

COUNTER SIDE CHAIR CTC130CSC

Caution: Please read instructions thoroughly before unpacking assembly parts. Sharp, exposed staple tips can cause injury, therefore, for your protection, please remove any exposed staples used in packing.

- 1. We recommend that you should assemble this product with the assistance of another person; this will make assembly easier, and will help to eliminate damage the product or injury to persons during assembly.
- 2. Be sure to check all packing materials carefully for small parts that may have come loose inside the carton during shipment.
- 3. Please do not over tighten screws or bolts.
- 4. Please put all parts on a non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.

PART LIST						
NO.	PART DESC	CODE	Q'TY			
Α	COUNTER SIDE CHAIR - UPHOLSTERED BACK FRAME	PCTC130CSCBFR	1			
В	COUNTER SIDE CHAIR - FULL SEAT CUSHION	PCTC130CSCSEA	1			
С	COUNTER SIDE CHAIR - LEFT / RIGHT FRONT LEGS SET	PCTC130CSCLEG	2			
D	COUNTER SIDE CHAIR - FRONT STRECHER	PCTC130CSCSTR1	1			
E	COUNTER SIDE CHAIR - LEFT / RIGHT SIDE STRECHER	PCTC130CSCSTR2	2			

HARDWARE LIST						
NO.	HARDWARE DESC		CODE	Q'TY		
1	@	BOLT Ø5/16"x80mm	PCTC130CSCHW	4		
2	@-mm	BOLT Ø5/16"x55mm		7		
3	0	LOCK WASHER Ø5/16"		11		
4	0	FLAT WASHER Ø5/16"		11		
5		ALLEN KEY M5		1		
6	8.mm	SCREW M8x45mm		6		

