


ASSEMBLY INSTRUCTION

SDM-2691A-8 / ARABAELA BS

Ax1 	Gx4+1 <u>EXTRA</u>  M6*16MM
Bx4 	Hx8+1 <u>EXTRA</u>  M6*25MM
Cx1 	Ix4+1 <u>EXTRA</u>  M6*30MM
Dx1 	Jx4+1 <u>EXTRA</u> 
Ex1 	Kx1 
Fx4+1 <u>EXTRA</u> 	Lx4+1 <u>EXTRA</u>  12*6*1MM

