Crosley 30" Free-Standing Self-Clean Electric Range

Model# XB258RMSS

Photo Not Available

 Removable full-width storage drawer - Large trays and other cookware can be conveniently stored for quick access

FEATURES	
Configuration	Range with Storage Drawer
Cooktop Burner Type	Coil
Cooktop Surface	One-Piece Upswept; Porcelain- Enamel
Control Location	Backsplash
Element - Left Front	6" 1250W Temp Limiting Coil
Element - Left Rear	8" 2400W Temp Limiting Coil
Element - Right Front	8" 2400W Temp Limiting Coil
Element - Right Rear	6" 1250W Temp Limiting Coil
Control Type	Digital Temperature Display; Electronic; Touchpads
Removable One-Piece Drip Bowls	Black Porcelain Enameled
Product Type	Free-Standing Single Oven
Heating Element "ON" Indicator Light	Yes
Lift-Up Cooktop With Support Rods	Yes
Oven Cleaning Type	Self-Clean
Oven Control Features	Audible Preheat Signal; Auto Oven Shut-Off with Override; Auto Self Clean; Control Lock Capability; Delay Bake Option (Time Bake); Delay Clean Option; Electronic Clock & Kitchen Timer; Hi / Low Broil; Oven "ON" Light; Self-Clean Cool Down Time Display; Self-Cleaning Cycling Light
Oven Features	6-Pass Bake Element; 6-Pass Broil Element
Oven Rack Features	2 Oven Racks; 6 Rack Positions
Storage Drawer Features	Removable Full-Width
Cooking Technology	Traditional
Cooktop Type	Coil
Drawer Type	Storage
Fuel Type	Electric
Oven Interior	1 Incandescent Light

Have more questions? Please contact 1-800-626-2005

Crosley 30" Free-Standing Self-Clean Electric Range

Model# XB258RMSS

APPROXIMATE DIMENSIONS (HxDxW)

• 47 in x 28 in x 30 in

CAPACITY

• Total Capacity (cubic feet) 5.30 cu ft

WARRANTY

- Parts Warranty Limited 1-year entire appliance
- Labor Warranty Limited 1-year entire appliance
- Warranty Notes See written warranty for full details

Have more questions? Please contact 1-800-626-2005