
For Model:

FD-BS-125C-CNT-K24

Description: 24" B/S, X-Back w/Cushion Seat




IMPORTANT NOTE:

- .Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched.
- . Check to be sure that you have all parts and hardware.
- . Remove all wrapping materials , including staples & packing straps before you start to assemble.
- .Do not tighten all screws/bolts until all completely assembled.
- . Keep all hardware parts out of reach of children.

	COMPONENT LIST	
NO	DESCRIPTION	QTY
1	CHAIR BACK	1 PC
2	BOX FRAME+ CUSHION SEAT	1 PC
3	FRONT LEG(Left & Right)	2 PCS
4	SIDE STRETCHER(Left & Right)	2 PCS
5	FRONT STRETCHER	1 PC

	HARDWARE LIST	
ITEM	DESCRIPTION	QTY
A	Wrench	1 PC
В	Bolt 5/16"*82mm	4 PCS
С	Bolt 5/16"*38mm	2 PCS
D	Nut 5/16"*6mm	4 PCS
E	Flat Washer	10 PCS
F	Spring Washer	10 PCS
G	Screw 44mm	6 PCS
Н	Glue Bottle	1 PC



For Model:

FD-BS-169C-CNT-K24

Description: 24" B/S, Ladder Back w/Cushion Seat




IMPORTANT NOTE:

- . Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched.
- . Check to be sure that you have all parts and hardware.
- . Remove all wrapping materials , including staples & packing straps before you start to assemble.
- . Do not tighten all screws/bolts until all completely assembled.
- . Keep all hardware parts out of reach of children.

	COMPONENT LIST	
NO	DESCRIPTION	QTY
1	CHAIR BACK	1 PC
2	BOX FRAME+ CUSHION SEAT	1 PC
3	FRONT LEG(Left & Right)	2 PCS
4	SIDE STRETCHER(Left & Right)	2 PCS
5	FRONT STRETCHER	1 PC

	HARDWARE LIST	
ITEM	DESCRIPTION	QTY
Α	Wrench	1 PC
В	Bolt 5/16"*82mm	4 PCS
С	Bolt 5/16"*38mm	2 PCS
D	Nut 5/16"*6mm	4 PCS
Е	Flat Washer	10 PCS
F	Spring Washer	10 PCS
G	Screw 44mm	6 PCS
Н	Glue Bottle	1 PC



For Model:

FD-BS-180C-CNT-K24

Description: 24" B/S, Slat Back w/Cushion Seat




IMPORTANT NOTE:

- .Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched.
- . Check to be sure that you have all parts and hardware.
- . Remove all wrapping materials , including staples & packing straps before you start to assemble.
- .Do not tighten all screws/bolts until all completely assembled.
- . Keep all hardware parts out of reach of children.

	COMPONENT LIST	
NO	DESCRIPTION	QTY
1	CHAIR BACK	1 PC
2	BOX FRAME+ CUSHION SEAT	1 PC
3	FRONT LEG(Left & Right)	2 PCS
4	SIDE STRETCHER(Left & Right)	2 PCS
5	FRONT STRETCHER	1 PC

	HARDWARE LIST	
ITEM	DESCRIPTION	QTY
A	Wrench	1 PC
В	Bolt 5/16"*82mm	4 PCS
С	Bolt 5/16"*38mm	2 PCS
D	Nut 5/16"*6mm	4 PCS
Е	Flat Washer	10 PCS
F	Spring Washer	10 PCS
G	Screw 44mm	6 PCS
Н	Glue Bottle	1 PC



Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment.

HARDWARE LIST:

a. NUT

5/16" 5/16"

5/16"

12PCS

b. WASHER

0

12PCS


c. Spring Washer 👩


12PCS

d. WRENCH

3

1 PC








FD-TA-L3645D-CNT-C

ASSEMBLY INSTRCTION

- Turn the table top upside down, place it on a flat and soft surface.
- Remove the legs from the boxes fixed on the bottom of the table.
- 3. Remove the plastic bolt protectors.
- Set the legs into the corner of the aprons, while aligning the hole in the corner with the bolt on the leg.
- Connect the Leg and the corner by using the nuts and washes supplied. Tighten the nuts firmly with the wrech.
- 6. Repeat for the other legs.
- 7. Turn the table right side up.


Hardware List

Nut © 8 pcs
Washer © 8 pcs
Lock Washer C 8 pcs
Wrench 1 pc



PARTS LIST

Table Top 1 pc Leg 4 pcs




FD-TA-L3678-CNT-C

ASSEMBLY INSTRCTION

- 1. Turn the table top upside down, place it on a flat and soft surface.
- Remove the legs from the boxes fixed on the bottom of the table.
- 3. Remove the plastic bolt protectors.
- Set the legs into the corner of the aprons, while aligning the hole in the corner with the bolt on the leg.
- Connect the Leg and the corner by using the nuts and washes supplied. Tighten the nuts firmly with the wrech.
- 6. Repeat for the other legs.
- 7. Turn the table right side up.


Hardware List

Nut	1	8 pcs
Washer	0	8 pcs
Lock Wash	ner C	8 pcs
Wrench	5=	1 pc



PARTS LIST

Table Top	1 pc
Leg	4 pcs
Leaf	1 pc





Assembly Instructions

MODEL: FD-TA-L4260-CNT-TOP 42"x42"-60" Laminate Table Top

MODEL: FD-TA-L4260-CNT-BSE 42"x42"-60" Laminate Table Pedestal

Step 1. Turn the pedestals up side down. Do not remove the plastic bolt protectors for this step.(Figure 1)

Step 2. Remove the plastic bolt protectors from the hanger bolts on the legs. Attach each leg to the pedestal using eight Nuts, eight Flat Washers and eight Lock Washers and tighten all nuts firmly with the wrench provided. (Figure 1)

Step 3. Turn the assembled pedestal right side up and place it in your desired location. Adjust the leg levellers at the bottom of each leg so that the pedestal remains solid without rocking. Remove the plastic bolt protectors before doing the next step.

Step 4. Place the open table top over the pedestal and align the holes in the table mounting boards with the bolts on the pedestal. Set the table down on the top of the pedestal. (Figure 2)

Step 5. Attach the pedestal to the mounting board as shown using four Nuts, four Flat Washers and four Lock Washers. Tighten all nuts firmly with the wrench provided.(Figure 2)

Step 6. Close the table top gently and latch all locks on the bottom of the table top.


*Check that all connections are tight and the table does not wobble before using.


Note: To extend the table, unlatch the locks on the bottom of the table top. Pull the table top apart gently and place the leaves into the open table top. Latch all locks on the bottom of the table top.

Thank you for purchasing this quality product. Carefully check all packing material for small parts which may have come loose inside the carton during shipment. Keep all hardware out of the reach of children. Study all of the instructions and drawings carefully before assembly. Check that all of the connections are tight and the product does not wobble before using.

PART	S CHECK LIST
Quantity	PART NAME
1	Table Top
4	Leg
1	Leaf
1	Pedestal

HARI	DWARE CHECK LIST
Quantity	PART NAME
12	Nut 🕤
12	Flat Washer
12	Lock Washer
1	Wrench 3





For Model: FD-CH-125C-CNT-RTA

Description: X-Back Side Chair w/Cushion Seat



DIPORTANT NOTE:

.Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched. Check to be sure that you have all parts and hardware.

Remove all wrapping materials , including staples & packing

straps before you start to assemble.

	∈	
	. Keep all hardware parts out of reach of children.	.Do not tighten all screws/bolts until all completely assembled
1		

5	COMPONENT LIST	
8	DESCRIPTION	ALC GIA
1	CHAIR BACK	1 PC
2	BOX FRAME+ CUSHION SEAT 1 PC	170
w	FRONT LEG(Left & Right)	2 PO
4	SIDE STRETCHER(Left & Right) 2 PCS	2 POS

AX ABPH ACFE ARCH ARCH ARCH ARCH ARCH ARCH ARCH ARC
5(ap:2 AX D F B 0 - 0 - 0 3(L)
riog:3

MADE IN CHINA

PAGE 1 OF 1

For Model:

FD-CH-169C-CNT-RTA

Description:Ladder Back Side Chair w/Cushion Seat




IMPORTANT NOTE:

- . Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched.
- . Check to be sure that you have all parts and hardware.
- . Remove all wrapping materials, including staples & packing straps before you start to assemble.
- .Do not tighten all screws/bolts until all completely assembled.
- . Keep all hardware parts out of reach of children.

COMPONENT LIST				
NO	DESCRIPTION	QTY		
1	CHAIR BACK	1 PC		
2	BOX FRAME+ CUSHION SEAT	1 PC		
3	FRONT LEG(Left & Right)	2 PCS		
4	SIDE STRETCHER(Left & Right)	2 PCS		

HARDWARE LIST			
ITEM	DESCRIPTION	QTY	
A	Wrench	1 PC	
В	Bolt 5/16**82mm	4 PCS	
С	Bolt 5/16**38mm	2 PCS	
D	Nut 5/16**6mm	4 PCS	
E	Flat Washer	10 PCS	
F	Spring Washer	10 PCS	
G	Screw 44mm	4 PCS	
Н	Glue Bottle	1 PC	



For Model:

FD-CH-180C-CNT-RTA

Description:Slat Back Side Chair w/Cushion Seat



IMPORTANT NOTE:

- . Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched.
- . Check to be sure that you have all parts and hardware.
- . Remove all wrapping materials, including staples & packing straps before you start to assemble.
- .Do not tighten all screws/bolts until all completely assembled.
- . Keep all hardware parts out of reach of children.

COMPONENT LIST				
NO	DESCRIPTION	QTY		
1	CHAIR BACK	1 PC		
2	BOX FRAME+ CUSHION SEAT	1 PC		
3	FRONT LEG(Left & Right)	2 PCS		
4	SIDE STRETCHER(Left & Right)	2 PCS		

HARDWARE LIST		
ПЕМ	DESCRIPTION	QTY
A	Wrench	1 PC
В	Bolt 5/16**82mm	4 PCS
С	Bolt 5/16**38mm	2 PCS
D	Nut 5/16**6mm	4 PCS
E	Flat Washer	10 PCS
F	Spring Washer	10 PCS
G	Screw 44mm	4 PCS
н	Glue Bottle	1 PC

