



## *ASSEMBLY INSTRUCTIONS*

### *COASTER FINE FURNITURE*



*Fine Furniture for every stage of life*

**651351**  
**Motion Sofa**

ITEM: **651351**



## ASSEMBLY INSTRUCTIONS

### ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



### WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME


5 MINUTES

## PARTS IDENTIFICATION

**A LEFT BACK 1PC**




**B MIDDLE BACK 1PC**



**C RIGHT BACK 1PC**



**D BASE 1PC**



**E LEFT EAR 1PC**



**F RIGHT EAR 1PC**




ITEM: **651351**


## ASSEMBLY INSTRUCTIONS




### STEP 1




### STEP 2





### STEP 3



### STEP 4 **COMPLETE**



ITEM: **651351**



**Note: Dimension tolerance  $\pm 5\%$**



## ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



*Fine Furniture for every stage of life*

**651352**  
***Glider Loveseat With Console***

ITEM: **651352**



## ASSEMBLY INSTRUCTIONS

### ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



### WARNING!


1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

5 MINUTES

## PARTS IDENTIFICATION

|   |              |                                                                                      |     |
|---|--------------|--------------------------------------------------------------------------------------|-----|
| A | LEFT BACK    |     | 1PC |
| B | RIGHT BACK   |   | 1PC |
| C | BASE         |  | 1PC |
| D | CONSOLE BACK |   | 1PC |
| E | LEFT EAR     |   | 1PC |
| F | RIGHT EAR    |   | 1PC |


## HARDWARE IDENTIFICATION

|   |                                |                                                                                      |      |
|---|--------------------------------|--------------------------------------------------------------------------------------|------|
| 1 | ADJUSTABLE SCREW<br>(Ø5/16"x2) |  | 2PCS |
|---|--------------------------------|--------------------------------------------------------------------------------------|------|


ITEM: **651352**

## ASSEMBLY INSTRUCTIONS


### STEP 1



### STEP 2





### STEP 3





POWER STRIP  
INSIDE OF STORAGE

### STEP 4 COMPLETE



ITEM: **651352**

**COASTER**  
FINE FURNITURE



**Note:** Dimension tolerance  $\pm 5\%$

COASTERFURNITURE.COM